


Original operating instructions

TOX[®] Powerpackage line-X

Type X-KT



TOX[®] PRESSOTECHNIK SE & Co. KG, Riedstrasse 4, 88250 Weingarten / Germany www.tox.com



Table of contents

1 Important information

1.1	Legal note	8
1.2	Exclusion of liability	8
1.3	Conformity	8
1.4	Validity of the document	9
1.4.1	Content and target group	9
1.4.2	Other applicable documents	9
1.5	Gender note	9
1.6	Displays in the document	10
1.6.1	Display of warnings	10
1.6.2	Display of general notes	11
1.6.3	Highlighting of texts and images	11
1.7	Contact and source of supply	12

2 Safety

2.1	Basic safety requirements	13
2.2	Organizational measures	13
2.2.1	Safety requirements for the operating company	13
2.2.2	Selection and qualifications of personnel	14
2.3	Fundamental hazard potential	15
2.3.1	Electrical hazards	15
2.3.2	Thermal hazards	15
2.3.3	Pneumatic hazards	15
2.3.4	Contusions	16
2.3.5	Hydraulic hazards	16
2.3.6	Electromagnetic hazards	17
2.3.7	Laser	17
2.3.8	Hazardous substances	17
2.3.9	Noise	18
2.3.10	Lithium ion battery	18



3 About this product

3.1	Intended use	. 19
3.1.1	Safe and correct operation	. 19
3.1.2	Safe and correct design and construction	. 20
3.1.3	Foreseeable misuse	. 20
3.2	Product Identification	. 21
3.2.1	Position and content of the type plate	. 21
3.3	Function description of TOX [®] Powerpackage with pressure regulator pre matic spring	
3.4	Product overview and product attributes of Powerpackage KT System	. 26
3.4.1	Product overview of TOX [®] Powerpackage X-KT system	. 26
3.4.2	Product overview and product attributes of TOX [®] Powerpackage type X-X-ATD	
3.4.3	Product overview and product attributes of TOX [®] Powerpackage type A ⁻ AT 51, ATSD, ATW	-
3.4.4	Product overview and product attributes of TOX [®] Powerpackage with int grated holding brake ZSL	
3.4.5	Product overview and product attributes of TOX [®] Powerpackage type HZ HZL 51, HZL - pulling, HZLW	,
3.4.6	Product overview of TOX [®] Powerpackage type RZHL, RZHLW	. 32
3.4.7	Product overview and product attributes of hydrosplit coupling ZHK	. 33
3.4.8	Product overview and product attributes of hydraulic hose lines	. 36
3.5	Optional equipment	. 37
3.5.1	Additional optional equipment	. 37
3.6	Product planning	. 38
3.6.1	Design data	. 38
3.6.2	Design principles	. 38
3.6.3	Air consumption	. 39
3.6.4	Cycle times	. 40
3.6.5	Performance optimization	. 41
3.6.6	Avoidance of dynamic oil leakage	. 41
3.6.7	Stroke limitation of the power stroke	. 43
3.6.8	Power limit of the power stroke	. 44
3.6.9	Speed reduction of the power stroke	. 44
3.6.10	Switchover of power stroke to return stroke for Powerpackage with hy- draulic damping (ZED, ZSD)	. 44
3.6.11	Holding brake (Assembly ZSL)	. 45
3.7	Activation and pressure control	. 46
3.7.1	Activation according to dynamic pressure method	. 46



3.7.2	Design principles of activation	46
4	Technical data	
4.1	Type sheet and data sheet	47
4.2	General environmental conditions	47
4.3	Ambient temperature	47
4.4	Compressed air quality and pneumatic connection	48
4.4.1	Pneumatic connection, air pressure, oil pressure	48
4.5	Tightening torques	48
4.5.1	Tightening torques for flange mounting the drive	48
4.5.2	Tightening torques on the piston rod	49
4.5.3	Tightening torques for total stroke adjustment (option)	49
4.5.4	Tightening torques of pneumatic screw fittings on the Powerpackage	
4.5.5	Tightening torques for hydraulic screwings	
4.5.6	Tightening torque of hydrosplit coupling ZHK	50
4.6	Press force table	51
4.7	Specification for hydraulic oil	51
5	Transport and storage	
5 5.1	Transport and storage Safety during transport	53
5.1	Safety during transport	54
5.1 5.2	Safety during transport Lifting device Temporary storages	54 54
5.1 5.2 5.3	Safety during transport	54 54
5.1 5.2 5.3	Safety during transport Lifting device Temporary storages	54 54
5.1 5.2 5.3 5.4	Safety during transport Lifting device Temporary storages Dispatch for repair	54 54 55
5.1 5.2 5.3 5.4 6	Safety during transport Lifting device Temporary storages Dispatch for repair	54 54 55 56
5.1 5.2 5.3 5.4 6	Safety during transport Lifting device Temporary storages Dispatch for repair Installation Safety during installation	54 55 56 57
5.1 5.2 5.3 5.4 6 6.1 6.2	Safety during transport Lifting device Temporary storages Dispatch for repair Installation Safety during installation Installing drive	54 54 55 56 57 58
 5.1 5.2 5.3 5.4 6 6.1 6.2 6.3 	Safety during transport Lifting device Temporary storages Dispatch for repair Installation Safety during installation Installing drive Connecting and separating hydrosplit coupling	54 54 55 56 57 58 60
5.1 5.2 5.3 5.4 6 6.1 6.2 6.3 6.4	Safety during transport Lifting device Temporary storages Dispatch for repair Installation Safety during installation Installing drive Connecting and separating hydrosplit coupling Installing hydraulic hose lines	54 54 55 56 57 58 60 61

6.5.3 Installing the external linear position sensor (ZHW) 65



6.5.4	Installing pressure control in the power stroke line (ZDK) 67
6.5.5	Installing proportional pressure control valve in the power stroke line 69
6.5.6	Installing external power stroke connection (ZKHZ) 70
6.5.7	Installing external power stroke release (ZKHF) and power stroke deactiva- tion (ZKHD)
6.5.8	Preparing external power stroke supply 72
6.5.9	Installing the stroke frequency optimization (ZHO)73
6.5.10	Installing the speed reduction for power stroke venting
6.5.11	Installing tool coupling (ZWK)

7 Commissioning

7.1	Safety during the commissioning	77
7.2	Requirements for the commissioning	77
7.2.1	Measuring connection and control connection	77
7.3	Setting control throttle 'X'	78
7.4	Setting speed ratio of return stroke to fast approach stroke	79
7.5	Set the speed ratio between power stroke and power stroke venting (op- tional)	79
7.6	Commissioning hydrosplit coupling ZHK	80
7.6.1	Commissioning hydrosplit coupling (manually switchable)	80
7.6.2	Commissioning hydrosplit coupling (with electrically switchable valve)	81
7.7	Setting total length of stroke (optional)	85
7.8	Setting the (ZED) damping (optional)	86
7.9	Setting cutting impact damping (ZSD) (optional)	89
7.9.1	Setting the damping effect	89
7.10	Setting the proximity sensors of the holding brake (ZSL) (optional)	91
7.11	Check the holding force of the holding brake	94

8 Operation

8.1	Safety in operation	95
8.2	Requirements for operation	96
8.3	Operating drive	96



9 Troubleshooting

9.1	Safety during troubleshooting	97
9.2	Searching for causes of fault on the Powerpackage	98

Maintenance table of Powerpackage

10 Maintenance

10.1	General information 101
10.2	Safety during maintenance 101
10.3	Requirements for maintenance 103
10.3.1	Set system to maintenance position 103
10.4	Checking oil level 104
10.5	Refilling oil and venting drive 105
10.6	Refilling oil and venting the drive of Powerpackage with optional equipment 109
10.6.1	Refilling oil and venting drive with integrated damping function ZED 109
10.6.2	Refilling oil and venting drive with cutting impact damping ZSD 114
10.7	Lowering of oil level 118
10.8	Check hydraulic hose lines 119
10.9	Replacing hydraulic hoses 120
10.10	Check the holding force of the holding brake 120

11 Repairs

11.1	Safety during repairs	121
11.2	Changing seals	121



12 Disassembly and Disposal

12.1	Safety during disassembly and disposal	122
12.2	Decommissioning	123
12.3	Shutdown	123
12.4	Disassembling	124
12.5	Disposal	125

13 Appendices

13.1	DECLARATION OF INCORPORATION	126

Index



1 Important information

1.1 Legal note

All rights reserved.

Operating instructions, manuals, technical descriptions and software published by TOX[®] PRESSOTECHNIK SE & Co. KG ("TOX[®] PRESSOTECHNIK") are copyright and must not be reproduced, distributed and/or otherwise processed or edited (e.g. by copying, microfilming, translation, transmission in any electronic medium or machine-readable form). Any use - including of extracts - contrary to this condition is prohibited without approval in writing by TOX[®] PRESSOTECHNIK and may be subject to criminal and civil legal sanctions.

If this manual refers to goods and/or services of third parties, this is for example only or is a recommendation by TOX[®] PRESSOTECHNIK.

TOX[®] PRESSOTECHNIK does not accept any liability or warranty/guarantee with reference to the selection, specifications and/or usability of these goods and services. The use and/or representation of trademarked brands that do not belong to TOX[®] PRESSOTECHNIK are for information only; all rights remain the property of the owner of the trademarked brand.

Operating instructions, manuals, technical descriptions and software are originally compiled in German.

1.2 Exclusion of liability

TOX[®] PRESSOTECHNIK has checked the contents of this publication to ensure that it conforms to the technical properties and specifications of the products or plant and the description of the software. However, discrepancies may still be present, so we cannot guarantee complete accuracy. The supplier documentation included with the system documentation is an exception.

However, the information in this publication is checked regularly and any required corrections are included in subsequent editions. We are grateful for any corrections and suggestions for improvement. TOX[®] PRESSOTECHNIK reserves the right to revise the technical specifications of the products or plant and/or the software or documentation without prior notice.

1.3 Conformity

The product is compliant with EU guidelines. See separate Declaration of conformity or installation declaration.



1.4 Validity of the document

1.4.1 Content and target group

This manual contains information and instructions for the safe operation and safe maintenance or servicing of the product.

- All information in this manual is up to date at the time of print. TOX[®] PRESSOTECHNIK reserves the right to make technical changes that improve the system or increase the standard of safety.
- The information is intended for the operating company as well as operating and service personnel.

1.4.2 Other applicable documents

In addition to the available manual, further documents can be supplied. These documents must also be complied with. Other applicable documents can be, for example:

- additional operating manuals (e.g. of components or of a whole system)
- Supplier documentation
- Instructions, such as software manual, etc.
- Technical data sheets
- Safety data sheets
- Data sheets
- Schematics

1.5 Gender note

In order to enhance readability, references to persons that also relate to all sexes are normally only stated in the usual form in German or in the corresponding translated language in this manual, thus e.g. "operator" (singular) for male or female, or "operators" (plural) for male or female". This should in no way convey any gender discrimination or any violation of the principle of equality, however.



1.6 Displays in the document

1.6.1 Display of warnings

Warning signs indicate potential dangers and describe protective measures. Warning signs precede the instructions for which they are applicable.

Warning signs concerning personal injuries

\Lambda DANGER

Identifies an immediate danger!

Death or severe injuries will occur if appropriate safety measures are not taken.

➔ Measures for remedial action and protection.

Identifies a potentially dangerous situation!

Death or serious injury may occur if appropriate safety measures are not taken.

→ Measures for remedial action and protection.

A CAUTION

Identifies a potentially dangerous situation!

Injury may occur if appropriate safety measures are not taken.

→ Measures for remedial action and protection.

Warning signs indicating potential damage

NOTE

Identifies a potentially dangerous situation!

Property damage may occur if appropriate safety measures are not taken.

➔ Measures for remedial action and protection.



1.6.2 Display of general notes

General notes show information on the product or the described action steps.



Identifies important information and tips for users.

1.6.3 Highlighting of texts and images

The highlighting of texts facilitates orientation in the document.

- ✓ Identifies prerequisites that must be followed.
- 1. Action step 1
- 2. Action step 2: identifies an action step in an operating sequence that must be followed to ensure trouble-free operation.
 - \triangleright Identifies the result of an action.
- Identifies the result of a complete action.
- → Identifies a single action step or several action steps that are not in an operating sequence.

The highlighting of operating elements and software objects in texts facilitates distinction and orientation.

- <In square brackets> identifies operating elements, such as buttons, levers and (valves) stopcocks.
- "with quotation marks" identifies software display panels, such as windows, messages, display panels and values.
- **In bold** identifies software buttons, such as buttons, sliders, checkboxes and menus.
- In bold identifies input fields for entering text and/or numerical values.



1.7 Contact and source of supply

Only use original spare parts or spare parts approved by TOX® PRESSOTECHNIK. TOX® PRESSOTECHNIK SE & Co. KG Riedstraße 4 88250 Weingarten / Germany Tel. +49 (0) 751/5007-767 E-Mail: info@tox-de.com For additional information and forms see www.tox.com



2 Safety

2.1 Basic safety requirements

The product is state of the art. However, operation of the product may involve danger to life and limb for the user or third parties or damage to the plant and other property.

For this reason the following basic safety requirements will apply:

- Read the operating manual and observe all safety requirements and warnings.
- Operate the product only as specified and only if it is in perfect technical condition.
- Remedy any faults in the product or the plant immediately.

2.2 Organizational measures

2.2.1 Safety requirements for the operating company

The operating company is responsible for compliance with the following safety requirements:

- The operating manual must always be kept available at the operation site of the product. Ensure that the information is always complete and in legible form.
- In addition to the operating manual, the generally valid legal and other binding rules and regulations must be provided for the following content and all personnel must be trained accordingly:
 - Work safety
 - Accident prevention
 - Working with hazardous substances
 - First aid
 - Environmental protection
 - Traffic safety
 - Hygiene
- The requirements and contents of the operating manual must be supplemented by existing national regulations (e.g. for prevention of accidents and for environmental protection).
- Instructions for special operating features (e.g. work organization, work processes, appointed personnel) and supervisory and reporting obligations must be added to the operating manual.



- Take action to ensure safe operation and make sure that the product is maintained in a functional condition.
- Only allow authorized persons access to the product.
- Ensure that all personnel work with awareness of safety and potential dangers with reference to the information in the operating manual.
- Provide personal protective equipment.
- Maintain all safety and information on dangers regarding the product complete and in legible condition and replace as required.
- Do not make any changes, carry out attachments or conversions to the product without the written approval of TOX[®] PRESSOTECHNIK. Action contrary to the above will not be covered by the warranty or the operating approval.
- Make sure that the annual safety inspections are carried out and documented by an expert.

2.2.2 Selection and qualifications of personnel

The following safety requirements are applicable for the selection and qualifications of personnel:

- Only appoint persons to work on the plant who have read and understood the operating manual, and in particular, the safety instructions before starting work. This is particularly important for persons who only work on the plant occasionally, e.g. for maintenance work.
- Only allow persons appointed and authorized for this work access to the plant.
- Only appoint reliable and trained or instructed personnel.
- Only appoint persons to work in the danger zone of the plant who can perceive and understand visual and acoustic indications of danger (e.g. visual and acoustic signals).
- Ensure that assembly and installation work and the initial commissioning are performed exclusively by qualified personnel who have been trained and authorized by TOX[®] PRESSOTECHNIK.
- Maintenance and repairs must be performed by qualified and trained personnel only.
- Ensure that personnel who are being trained, instructed or are in an apprenticeship can only work on the plant under the supervision of an experienced person.
- Have work on electrical equipment performed only by electricians or trained persons under the direction and supervision of an electrician in accordance with the electrotechnical regulations.



2.3 Fundamental hazard potential

Fundamental hazard potentials exist. The specified examples draw attention to known hazardous situations, but are not complete and do not in any way provide safety and risk awareness action in all situations.

2.3.1 Electrical hazards

Attention should be paid to electrical hazards particularly inside the components in the area of all assemblies of the control system and motors of the installation. The following basically applies:

- Have work on electrical equipment performed only by electricians or trained persons under the direction and supervision of an electrician in accordance with the electrotechnical regulations.
- Always keep the control box and/or terminal box closed.
- Before commencing work on electrical equipment, switch off the main switch of the system and secure it against being switched back on inadvertently.
- Pay attention to the dissipation of residual energy from the control system of the servomotors.
- Make sure that the components are disconnected from the power supply when carrying out the work.

2.3.2 Thermal hazards

During operation piece parts may become hot and cause burns when touched. Hazardous positions are generally marked with a symbol. See Safety symbols

- Wear individual protective equipment.
- Before starting work, make sure that surfaces have cooled down sufficiently.

2.3.3 Pneumatic hazards

Attention must be paid to pneumatic hazards particularly on the pneumatic supply lines and connection points.

The following basically applies:

- Allow work to be carried out on pneumatic equipment by authorized service personnel only.
- Wear individual protective equipment.



- Do not exceed the permissible pressure.
- First switch on compressed air when all hose connections have been established and secured.
- Do not uncouple any hoses under pressure.
- If hoses slip off, switch off the compressed air supply immediately.

2.3.4 Contusions

Contusions and hand injuries can occur in the radius of action of the product. The following applies generally:

- Make sure that that no persons are located in the danger area during operation.
- During necessary work in the danger area (e.g. maintenance, cleaning), secure the system against unexpected, accidental and unauthorized activation.
- Make sure that parts or tools cannot fall down or descend as a result of stored energy. Use appropriate fuses.

2.3.5 Hydraulic hazards

Attention must be paid to hydraulic hazards particularly on the supply lines, connection points and vent points.

The following applies generally:

- Allow work to be carried out on hydraulic equipment by authorized service personnel only.
- Wear individual protective equipment.
- Do not exceed the permissible pressure.
- Do not remove any hoses under pressure.
- Never vent hydraulic components under pressure.



2.3.6 Electromagnetic hazards

Electromagnetic hazards are to be taken into account in the area of electromagnetically vibrating or oscillating components.

Regular work on and with electromagnetically vibrating or oscillating components can cause disorders in the blood flow of the fingers as well as neurological and motoric dysfunctions.

The following applies generally:

- Wear protective anti-vibration gloves when performing necessary work!
- Electromagnetic fields can have an indirect effect on heart pacemakers and other implants. Adhere to safety distances.

2.3.7 Laser

Depending on the model and features, lasers can be installed for the purpose of recognition. There is a danger of looking into the laser in some situations. If this is not avoided, eye injuries may result.

The following applies generally:

- Do not look into the direct or the reflected beam.
- If the laser beam hits the eye, deliberately close the eyes and move the head immediately out of the beam.
- When using the laser, no optical instruments are to be used for viewing the source of the beam, since this can lead to exceeding the exposure limit values.
- Manipulation (modification) of the laser equipment is inadmissible.

2.3.8 Hazardous substances

The following safety requirements apply when handling chemical substances:

- Observe the applicable safety regulations on handling chemical substances and the information on the manufacturer's safety data sheets of hazardous substances.
- Wear individual protective equipment.
- In the event of eye or skin contact, rinse the affected area, change contaminated clothing and visit a doctor if necessary. Provide appropriate equipment (eye wash bottle, washbasin) near the workplace.
- Groundwater hazardous substances must not get into the ground or sewage system. Collect groundwater hazardous substances and dispose of them properly.



2.3.9 Noise

Depending on the equipment, an increase in the noise level can arise in the sphere of the product.

- Keep the duration of the exposure at a minimum.
- Wear individual protective equipment.

2.3.10 Lithium ion battery

Lithium ion (Li-Ion) batteries are a hazardous material.

The following safety requirements apply for handling:

- Check the battery before use for damage. Damaged Li-lon batteries must no longer be used or charged.
- Do not drop batteries, throw them, subject them to shocks or other mechanical stress, which could lead to damaging the batteries.
- After a mechanical effect due to a crash, impact or contusion, the further use and charging of the battery is prohibited.
- Due to improper use, fluid (electrolyte) can escape from the battery. Avoid contact with liquids, and, in case of contact, thoroughly clean the affected point with water. If the liquid entered the eyes, contact a doctor immediately.
- If the operating period of a battery is found to lessen considerably, the use is to be stopped immediately and the battery is to be replaced. Otherwise there is the hazard of overheating and explosion.
- Ensure that the battery cannot be short-circuited.
- Do not subject the battery to rain nor dip it into conductive liquids (e.g. water, beverages, etc.).
- Do not burn batteries since the battery can explode at high temperatures in the fire.



3 About this product

3.1 Intended use

The hydropneumatic drive performs the strokes that are generally defined as fast approach stroke, power stroke and return stroke. The drive is intended for installation in machines or robot tongs with the following technical applications:

- Installing, pressing
- Punching, pressing (of function elements)
- Riveting, crimping, flaring
- Punching, piercing
- Embossing, marking
- Tensioning, clamping, crimping
- Pressing, compressing
- Clinching, joining

This incomplete machine may not be commissioned until it has been ascertained that the incomplete machine in which the component is to be installed complies with the requirements of the Machinery Directive (2006/42/EC).

3.1.1 Safe and correct operation

Intended use includes the following conduct:

- Only operate with the components for which it is specified.
- Follow all instructions in this operating manual.
- Comply with the specified maintenance intervals and perform maintenance work correctly.
- Operate in compliance with the conditions of the technical data.
- Operation with fully assembled and functional safety devices.
- Activities may only be carried out by persons who are qualified or authorized for this purpose.

Any other use or application beyond this does not come under the scope of intended use.



3.1.2 Safe and correct design and construction

The generated forces can be immense in case of different applications! This can lead to damage or breakage of material. This can cause dangerous situations during operation!

The following aspects are an intrinsic part of the intended design and construction:

- The design and construction must at all time guarantee that the maximum generated forces do not lead to the failure or to a breakage of system components.
- Especially during punching and hole applications must the dynamic forces be effectively limited.
- The dynamic forces must at no time exceed the maximum admissible (static) press forces in the direction of pressure and tension. These are specified for every drive of TOX[®] PRESSOTECHNIK.
- Dynamic forces must be limited with suitable precautionary measures to ensure that the admissible (static) press forces are not exceeded.
- Suitable precautionary measures can be as follows:
 - Dampings in the tool
 - Limit of the maximum accelerations,
 - Use of optional modules such as damping of cutting impact or press-in
 - etc.
- It must be ensured that there is no unauthorized, inadvertent, mistaken rise of the dynamic and static press forces and return stroke forces designed for the application during operation.

If the Powerpackage is to be installed in movable applications (movable carriages, robots, etc.), the maximum occurring acceleration and brake forces must not exceed the 5-fold of the dead weight of the Powerpackage. Higher brake forces can cause danger to the life and limb of the user and damage to the drive.

Non-observance of and non-adherence to the maximum admissible press forces and return stroke forces is not valid as intended use and is not permitted.

3.1.3 Foreseeable misuse

Use contrary to intended use includes the following foreseeable misuse:

- Operation under conditions that deviate from the technical data.
- Operation without fully assembled and functional connections.
- Operation without fully assembled and functional safety devices.
- Modifications to the product without prior approval by TOX[®] PRESSOTECHNIK and the approving authority.



- Incorrect parameterization.
- Execution of activities by persons who are not qualified or authorized to do so.

The operating company is exclusively responsible for all personal injury and property damage resulting from non-intended use. Non-intended use will not be covered by the warranty or the operating approval.

3.2 Product Identification

3.2.1 Position and content of the type plate

Designation on the type plate	Meaning
Туре	Product designation
No.	Serial number
ΔV [ml]	Lowering volume
	Indicates the amount of oil that must be dis- charged again after completely filling.
P _{max}	Maximum pressure



Type code structure

3.3 Function description of TOX[®] Powerpackage with pressure regulator pneumatic spring

The drive works with a pneumatically operated cylinder with pneumohydraulic power stroke. At the same time, a closed oil cylinder and valve system is driven with compressed air, which is controlled in the same way as a double-acting pneumatic cylinder.

Compressed air is converted to oil pressure in the intensifier part to generate the necessary press force for the power stroke. In the working part, the oil pressure acts on the working piston.

The compressed air is also used for the fast approach of the working piston to the working position (fast approach stroke) and for the return to the home position (return stroke).





Fig. 1 Starting position

- In home position, the drive is controlled via the main control valve in the return stroke.
- The working piston is retracted.





Pneumatically operated fast approach stroke

Fig. 2 Fast approach stroke

- After switching over the main control valve to forward stroke, compressed air enters the fast approach stroke chamber. The return stroke chamber is being vented.
- The power stroke valve is supplied with compressed air.
- The working piston extends with a fast approach stroke.
- The feed piston pushes hydraulic oil from the reservoir into the high pressure chamber activated by the pressure valve (pneumatic spring).
- As soon as the working piston meets any resistance, it stops.
- The power stroke valve switches over independently to power stroke after a delay, depending on the air volume flowing out of the control throttle 'X'.



Pneumohydraulic power stroke




Fig. 3 Power stroke

- Compressed air from the forward stroke connection penetrates into the power stroke chamber of the intensifier piston via a connection line.
- The plunger passes through the high pressure seal and separates the oil chamber into a working area and an oil reservoir.
- A hydraulic pressure is generated in working area, which creates the power stroke via the working piston.



Return stroke




Fig. 4 Return stroke

- The main control valve is switched over to return stroke by a signal. The return stroke chamber is being filled with compressed air.
- As a result, the power stroke valve is vented and moved to the home position.
- The power stroke chamber of the intensifier piston is vented via the muffler and the return stroke is triggered.
- After the intensifier piston has released the high pressure seal, the working piston moves back to the home position.



3.4 Product overview and product attributes of Powerpackage KT System

3.4.1 Product overview of TOX[®] Powerpackage X-KT system




Fig. 5 Product overview of TOX® Powerpackage X-KT system

Product attributes of TOX® Powerpackage X-KT system

Several combinations are available. These depend on the required forces, cycle time and available dimensions.

- Use the X-AT and X-ES combination when high approach and retract forces, as well as fast approach speeds are required.
- The HZL and X-ES combination is to be recommended when a short cylinder and a cost effective solution is needed.

Type X-KT with X-ES and X-AT			Type X-KT with X-ES and HZL		
۰	Working part X-AT is connected to the intensi- fier X-ES by a high pressure hose.	•	Hydraulic cylinder type HZL is connected to the intensifier X-ES by a high pressure hose.		
۰	Working part X-AT with pneumatic fast approach stroke line supplied from the intensifier X-ES.	•	Fast approach stroke via hydraulic line, supplied from the intensifier X-ES.		



Type X-KT with X-ES and X-AT			Type X-KT with X-ES and HZL		
۰	Fast approach stroke and return stroke occur by means of pressurization on the working part X-AT.		Fast approach stroke and return stroke occur by neans of pressurization on the intensifier X-ES.		
•	Return stroke via pneumatic return stroke line supplied by intensifier X-ES.		Return stroke via pneumatic return stroke line supplied by intensifier X-ES.		
•	Fixed stop with elastomer cushioning in the lower final position.	• F	Fixed stop		
		C	Optional with elastomer cushioning.		
•	Power bypass ZLB including hydraulic end position cushioning ZHD in the upper final position.	• F	Power bypass ZLB.		
•	Power stroke valve with pressure valve (pneumatic spring) and fast stroke support.				
•	It is also possible for one intensifier to drive a number of working parts by using an appropriate ZHK coupling.				
•	Pneumatic distribution strip with air connection for forward stroke and return stroke.				
•	Hydrosplit coupling ZHK.				
•	Prepared for stroke monitoring ZHU (up to and including X-AT 30).	• (Optional: Prepared for stroke monitoring ZHU.		
٠	Prepared for external linear position sensor ZHW (up to and including X-AT 30).	• (Optional: integrated linear position sensor ZKW.		

3.4.2 Product overview and product attributes of TOX[®] Powerpackage type X-AT, X-ATD





Fig. 6 Product overview of TOX[®] Powerpackage type X-AT, X-ATD





Product attributes of TOX® Powerpackage type X-AT, X-ATD



Characteristics

Type X-AT

- Working part X-AT with two bearing working pistons.
- · Fast approach stroke and return stroke by means of pressurization on the working part.
- High fast approach stroke forces and return stroke forces. Power stroke with intensifier X-ES.
- Fixed stop with elastomer cushioning in forward stroke.
- Hydraulic final position damping of return stroke.
- With power bypass ZLB.
- Prepared for stroke monitoring ZHU (up to X-SD 30, EL 30).
- Prepared for external linear position sensor ZHW (up to X-SD 30, EL 30).

Type X-ATD

Additional characteristics

• With integrated damping function.

Allows a selectable constant speed of the working piston during the approach stroke and power stroke, independent of the respective working forces.

Manually adjustable flow control valve or optional electrically operated adjustable proportional current regulation valve.

- The oil pressure cannot be used as signal for the return stroke. To switch over from power stroke to return stroke, a distance-dependent signal must be selected.
- Including external power stroke connection (ZKHZ).



3.4.3 Product overview and product attributes of TOX[®] Powerpackage type AT, AT 51, ATSD, ATW





Fig. 8 Product overview of TOX[®] Powerpackage type AT, AT 51, ATSD, ATW


Product attributes of TOX[®] Powerpackage type AT, AT 51, ATSD, ATW

Cł	naracteristics
Ту	ире АТ
•	Working part AT with two bearing working pistons.
•	Fast approach stroke and return stroke by means of pressurization on the working part.
•	High fast approach stroke forces and return stroke forces. Power stroke with intensifier ES.
•	Elastomer damping in forward stroke. Optional with fixed stop in forward stroke.
•	With power bypass ZLB (no hydraulic end position damping ZHD)
A٦	F 51 (additional characteristics)
•	Equipped with total stroke adjustment.
	The length of the total stroke distance can be adjusted independently of the length of the power stroke.
Ту	pe ATSD (additional characteristics)
•	Equipped with total stroke adjustment.
	The length of the total stroke can be adjusted independently of the length of the power stroke and the length of the cylinder.
•	Equipped with cutting impact damping.
	Makes adjustable damping possible during punching applications or damped operation of machines to the last 6-8 mm of the total stroke.
•	The oil pressure cannot be used as signal for the return stroke. To switch over from power stroke to return stroke, a distance-dependent signal must be selected.
Ту	vpe ATW (additional characteristics)
•	Equipped with integrated linear position sensor.



3.4.4 Product overview and product attributes of TOX[®] Powerpackage with integrated holding brake ZSL





Product attributes of TOX[®] Powerpackage with integrated holding brake ZSL

Integrated holding brake ZSL					
Α	Additional characteristics				
٠	 Integrated holding brake (Safety Lock) (for almost all series) 				
	The holding brake is held open pneumatically and responds at a drop in pressure. The energy of the crashing or dropping load is used for generating the clamping force.				



Product overview and product attributes of TOX[®] Powerpackage 3.4.5 type HZL, HZL 51, HZL - pulling, HZLW





Fig. 10 Product overview of TOX® Powerpackage type HZL, HZL 51, HZL - pulling, HZLW

Product attributes of TOX[®] Powerpackage type HZL, HZL 51, HZL pulling, HZLW

Characteristics Type HZL					
					 Short design and a simple bearing working piston.
•	Fast approach stroke and power stroke are supplied by intensifier X-ES. For the return stroke the hydraulic cylinder is impinged with compressed air.				
٠	Fixed stop in forward stroke.				
•	Power bypass for oil system protection.				
•	Optionally the HZL can be equipped as pulling working cylinder.				
Ту	rpe HZL 51 (additional characteristics)				
•	Equipped with total stroke adjustment.				
	The length of the total stroke distance can be adjusted independently of the length of the power stroke.				
Ту	vpe HZLW (additional characteristics)				
	Equipped with integrated linear position sensor ZHW				

Equipped with integrated linear position sensor ZHW.





3.4.6 Product overview of TOX[®] Powerpackage type RZHL, RZHLW

Fig. 11 Product overview of TOX® Powerpackage type RZHL, RZHLW



Product attributes of TOX[®] Powerpackage type RZHL, RZHLW

Cł	naracteristics
٠	For use in robot tongs and machine tongs.
٠	For the return stroke the hydraulic cylinder is impinged with compressed air.
Ту	pe RHZL (additional characteristics)
٠	Partly equipped with total stroke adjustment.
	The length of the total stroke distance can be adjusted independently of the length of the power stroke.
٠	Setting the total stroke on the RZH (version .00 and .30). For version .200 the adjustment is made via the precision shim plates on the tool.
RZ	ZHLW (additional characteristics)
•	Equipped with integrated linear position sensor.

3.4.7 Product overview and product attributes of hydrosplit coupling ZHK

With the TOX[®]- hydrosplit couplings ZHK the pressure transmitters and drive cylinders can be isolated without the entry of air or oil leakage (e.g. for transport and installation). It is available in a version that can be switched manual or electrical.

With the hydrosplit coupling that can be switched electric, several working cylinders connected to an intensifier can be switched alternately.

Hydrosplit coupling ZHK, manually switchable

Type: ZHK 018.000, ZHK 020.000, ZHK 042.000




Fig. 12 Hydrosplit coupling ZHK, manually switchable

Туре	Screws Pos. 5	Screws Pos. 6	Screws Pos. 7	Hydraulic lineconnection
ZHK 018.000	M 8 / 27 Nm	M 10 / 60 Nm	10 Nm	G 3/4"
ZHK 020.000	M 8 / 27 Nm	M 10 / 60 Nm	10 Nm	G 1"
ZHK 042.000	M 20 / 425 Nm	M 20 / 425 Nm	20 Nm	SAE 2

Tab. 1 Tightening torques, Hydraulic line connection

Hydrosplit coupling ZHK, with electrically switchable valve

Type: ZHK 018.001, ZHK 020.001

With the electrically switchable TOX[®]- hydrosplit couplings type ZHK, the hydraulic lines of the connected working cylinders AT/X-AT or HZL can be switched on and off with an integrated pneumatic cylinder.

Usable for drives up to size HZL 74 / X-AT 050.

- Activation and deactivation of the working cylinder with controllable pneumatic cylinder with loss of pressure
- Individual activation of different cylinders, positioning also during return stroke
- Only one valve size for all cylinders
- Improved cycle time
- Prepared for switching position request




Fig. 13 Hydrosplit coupling ZHK, with electrically switchable valve



Specification / Technical data

- Operating voltage:24 V / DC
- Power consumption: 4.4 W
- Weight approx.: 7.5 kg
- Closing force of spring pressureless: 160 N
- Min. switching pressure: 3 bar
- Max. switching pressure: 10 bar
- Prepared for switching position request via magnetic field sensors

Including valve plug DIN 43650 (ISO 4400), design A, with LED

Pneumatic, hydraulic and electric connections

- Connection size for pneumatic pressure supply: G 1/4"
- Valve plug DIN 43650 (ISO 4400), design A, contact distance 18 mm, protective conductor (PE) bridged, with LED display
- Flange cover suited for valves with ISO 1 connecting diagram

Туре	Screws Pos. 5	Screws Pos. 6	Screws Pos. 7	Hydraulic lineconnection
ZHK 018.001	M 8 / 27 Nm	M 10 / 60 Nm	10 Nm	G 3/4"
ZHK 020.001	M 8 / 27 Nm	M 10 / 60 Nm	10 Nm	G 1"

Tab. 2 Tightening torques, Hydraulic line connection

Accessories hydrosplit coupling ZHK, with electrically switchable valve

- Magnetic field sensor M8x1/BMF21K/HW8/ST (mat no. 180651)
- Holding angle BMF 21-HW-10 and in stainless steel BMF 21-HW-10-E for pneumatic cylinder with housing-integrated drawbar (profile)

ISO valve (5/2-way magnetic valve, series ISO1)

Specification / Technical data

- Nominal flow: 1060 l/min
- Admissible medium: compressed air, oiled or oil-free
- Operating voltage:24 V/DC
- Power consumption: 24 V/DC: 4.4 W
- Protection type with line socket: IP65 (DIN VDE 0470)
- Weight: 0.46 kg



- Magnetic coil 8 x45 rotatable
- Standardized line socket 4 x 90° turnable, standardized connections
- Non-detachable fastening screws and plate seal
- Plate connection, can be mounted in any orientation
- Pilot valve with CNOMO connecting surface
- Valve connecting hole diagrams according to ISO 5599

3.4.8 Product overview and product attributes of hydraulic hose lines

The hydraulic hoses are dimensioned in the factory so that adherence to the maximum admissible operating pressure requires no additional measures such as re-mantling with additional protective hoses are necessary. However, for TOX[®] PRESSOTECHNIK all hydraulic hoses are supplied with an additional burst-protected hose and meet the applicable standard EN 16092-1 (tool machine safety - presses - part 1: general safety requirements)

(i)

If hydraulic components are installed by the customer, the national legal provisions for the hydraulic components used must be adhered to. TOX[®] PRESSOTECHNIK does not accept responsibility nor provide warranty for the assembly of hydraulic components at the customer. This applies in particular also to later conversions in the area of hydraulic lines and screw fittings.

Identification of hydraulic hoses




Fig. 14 Identification of hydraulic hoses



3.5 Optional equipment

3.5.1 Additional optional equipment

Туре	Product attributes
ZKW	Travel measuring system
	• The travel sensor indicates the absolute actual position of the piston.
	 For internal installation (only for series X-K 050 / 75 / 100 / 170).
ZKW	Travel measuring system
	 The travel sensor indicates the absolute actual position of the piston.
ZHW	Travel measuring system
	 The travel sensor indicates the absolute actual position of the piston.
	 For external installation (for series line-Q and line-X to Q-S/Q-K 30, X-SX-K 30).
ZHU	Stroke monitoring
	 Determines the position of the working piston during forward stroke and return stroke via the external sen- sor.
ZDK	Pressure regulation in power stroke line
	 Make possible the individual adjustment of the press force with a manual pressure valve or electrical propor- tional valve.
ZKHZ	External power stroke connection
	• Enables the connection of the power stroke valve with an electrically actuated 3/2-way valve.
ZWK	Tool coupling
	 Connects the drive and tool flexibly to prevent trans- verse forces from affecting the drive.
ZDO	Electronic pressure switch
	 Records the oil pressure in the high-pressure part as system pressure and visualizes it via a four-digit LED display.
	 The set switching function allows 2 output signals to be created.
ZHO	Stroke frequency optimization
	Reduces the cycle time.
	 Replaces the existing power stroke valve with one of the next size.
ZPS	Pressing force sensor
	 Measures the press forces in the direction of the pressure.

For optional equipment, see data sheet and brochure TOX[®] Powerpackage. <u>http://tox-pressotechnik.com/</u>



3.6 Product planning

3.6.1 Design data

Data sheet

For technical data and installation dimensions see data sheet. (<u>http://www.tox-pressotechnik.de</u>)

3.6.2 Design principles

- When fastening, note the following:
 - Installation dimensions
 - Weight, including weight of the accessories
 - Press force
 - Loads caused by the working process (dynamics and vibrations)
- No transverse forces may act on the piston rod.
 If necessary, use a linear guide for the working piston: either a ram plate and guiding columns or a guiding rail with guiding carriage.
- In the case of horizontal installation the connection side must face upwards.
- Elements requiring servicing maintenance, such as oil filling nipple, vent hole, high pressure measuring connection, control throttle,X⁴ and oil level indicator should be accessible.
- Make sure that the ventilation of the hydraulic system is always possible even when installed.
- The space requirement for supply lines must be taken into consideration.
- The length of the hose lines, the connection of an oil pressure switch or oil pressure monitor can significantly reduce the power stroke.



3.6.3 Air consumption

- For the air consumption, the fast and return stroke are calculated with the available air pressure.
- The air requirement in the power stroke is calculated depending on the required press force.

For example, this depends on when the required oil pressure is reached.

• If the intensifier chamber is filled with complete air pressure, the air consumption can indeed be higher than the requirement that is actually needed and calculated.

In general, the specification for the air requirement includes all filling processes required for a stroke. The information only refers to the specific drive.

For hoses and valves - in particular for long hoses with large cross sections - which are filled and ventilated together with the drive, their consumption must also be considered when selecting a compressor.

The following applies here: Energy-saving are short lines from the valve to the drive.

When using pressure regulators (e.g. for the pneumatic spring), low internal air consumption cannot be avoided. This is usually in the range of a few liters per hour. Similarly, there might be air losses in the hose and valve connections. In order to avoid air losses, e.g. at night, the drive can be depressurized during this time.

Risk of personal injury due to the lowering of the working piston

There is a risk of crushing when the working piston lowers.

The working piston of a Powerpackage/ KT system can only be safely held up with sufficient return stroke pressure and sufficient air supply!

In the event of a compressed air failure, no return stroke will be initiated! Depending on the size of the drive and the weight of the tool used, a slow lowering of the working piston is possible.

- → Use a controlled check valve or holding brake (ZSL) or mechanical holding device, especially with large tool weights.
- If controllable valves are installed as pneumatic holding brake at the customer, the corresponding safety regulations are to be observed and adhered to.



3.6.4 Cycle times

The cycle time is calculated depending on the required press force. The following applies:

- The smaller the effective press force, the shorter the cycle time.
- An effective press force over 90 % should be avoided.
- The switching times of the valves and controls upstream of the drive must be taken into consideration for the specified cycle times.

Requirement for achieving the calculated times:

Air pressure

The required air pressure is the result of the desired effective press force. To achieve a short cycle time, an air pressure as high as possible is recommended for fast and return stroke. If the maximum press force of the cylinder is to be reduced, this can be realized with a pressure control ZDK (manual or electric) in the power stroke line.

Cross-section of hose

The line cross sections must at least match the connection sizes provided in order to achieve the calculated cycle time. This applies also to the regulation valves and maintenance units installed upstream of the drive. Reduced line cross sections can considerably reduce the cycle time. Reduced line cross sections can lead to oil leakages on the powerpackage, see Avoidance of dynamic oil leakage, Page 41.

• Tube lengths

The length of the hoses should be kept to a minimum, since the air consumption as well as the cycle time are increased with the length.

Compressor performance

The compressor performance should always be sized with sufficient safety.

Speed setting

The speed can be regulated as required by installing throttle check valves in the fast approach stroke and return stroke lines (except for type RP, T). Furthermore, the speed of the power stroke can be adjusted by mounting a throttle in the power stroke line of the unit. The drive can thus also be used for special applications, such as pressing in bushes, projecting etc.

Optimization of stroke frequency ZHO

The cycle time specifications correspond in general only to the entire drive under realistic conditions. If necessary, the cycle time can be further reduced using our optional accessory module ZHO.



3.6.5 Performance optimization

The ratio of the speed between the return stroke and the fast approach stroke must be set in order to ensure optimum performance.

- An optimum speed ratio between fast approach stroke and return stroke.
- A balanced power stroke speed.
- Adequately sized connection sizes (cross-section of hose, switching valves, maintenance unit) that prevent a reduction of the power stroke speed.

For technical data and installation dimensions see data sheet. www.tox.com

3.6.6 Avoidance of dynamic oil leakage

The dynamic oil leakage is based on the physical effect of drag flow: the higher the speed, the thicker the oil film dragged along. In the case of an unfavorable speed ratio between the fast approach stroke and return stroke, an oil film could get into the pneumatic chambers of the TOX[®] Powerpackage.

The following applies:

- The ratio of the speed between the return stroke and the fast approach stroke must be set.
 - For setting the speed ratios, also the exhaust air dampers must be installed on the fast approach stroke connections and the return stroke connections.
- A balanced power stroke speed.
 - For the attuned power stroke speed an exhaust air damper must also be installed in the power stroke venting.
- For the throttled power stroke speed, the speed ratios between power stroke speed and venting of the power stroke must be set.
 See Installing the speed reduction for power stroke venting, Page 75.
- The power cross sections to the TOX[®] Powerpackage (hose cross sections, switching valves, maintenance unit) must at least meet the specifications in the type sheet.

For technical data and installation dimensions see data sheet. www.tox.com



Setting speed ratio of return stroke to fast approach stroke

The speed of the working piston in the fast approach stroke and return stroke can be set with external exhaust air dampers on the forward stroke and return stroke. The exhaust air dampers may have to be retrofitted.

Ne	cessary speed ratio
Hy	fraulic cylinder HZL
•	Forward stroke equally fast or up to max. 20% faster than the return stroke
Hy	draulic cylinder HZL with total stroke adjustment
•	Forward stroke equally fast as return stroke
W	rking part X-AT, AT
•	Return stroke equally fast or faster than the forward stroke
W	rking part AT with total stroke adjustment
•	Forward stroke equally fast as return stroke

Tab. 3 Necessary speed ratio

 (\mathbf{i})

A visual check of the speeds is generally sufficient.

- 1. Set speed ratio according to the specifications.
- 2. Perform test and check the speed visually.

Set the speed ratio between power stroke and power stroke venting (optional)

At throttled power stroke speed Necessary speed ratio between power stroke and power stroke venting • Power stroke speed equal to the return stroke speed of the intensifier piston or • Power stroke speed faster than the return stroke speed of the intensifier piston

Tab. 4 Necessary speed ratio



A visual check of the speeds is generally sufficient.

- 1. Set speed ratio according to the specifications.
- 2. Perform test and check the speed visually.



3.6.7 Stroke limitation of the power stroke

For applications that require a fixed end stop, the total stroke of the drive can be limited.

For punch applications a limiting the travel of the power stroke must take place. The travel of the power stroke must be limited to a maximum of 80%.

The travel of the power stroke can be limited by:

- Stroke limitation in the tool.
- Stroke limitation by a set total stroke (fast approach stroke and power stroke).
- Stroke limitation by setting the total stroke length and cutting impact damping (ZSD).

Stroke limitation of the power stroke in the tool




Fig. 15 Stroke limitation in the tool

After the punching process the tool limits the power stroke (LDC).

Stroke limitation due to use of the internal fixed stop

Aside from the stroke limitation in the tool, also the internal fixed stop in the drive at the end of the total stroke (fast approach stroke+power stroke) can be used.

If required, the total stroke can be reduced to the necessary total stroke when placing the order.



3.6.8 Power limit of the power stroke

It is possible to monitor the press force of the power stroke by connecting an oil pressure switch or an oil pressure monitor. Upon reaching the desired press force, the return stroke must be induced.

The press force can be reduced permanently by installing a pressure control in the power stroke line.



An oil pressure of at least 30 bar is necessary for pressure control in the power stroke line (ZDK).

3.6.9 Speed reduction of the power stroke

The speed of the power stroke can be reduced if a control throttle is installed in the supply line for the power stroke.

To prevent a dynamic oil leakage, an additional exhaust throttle must be installed in this case so that the speed ratio can be adjusted.

See Installing the speed reduction for power stroke venting, Page 75.

3.6.10 Switchover of power stroke to return stroke for Powerpackage with hydraulic damping (ZED, ZSD)

For drives with hydraulic damping (ZED, ZSD) there is an increase in oil pressure in the power stroke. The oil pressure can therefore not be used as signal for the return stroke.

To switch over from power stroke to return stroke, a distance-dependent signal must be selected.



3.6.11 Holding brake (Assembly ZSL)

The following applies for the installation and use of the holding brake (ZSL):

- The holding brake serves exclusively for the mechanical safety of a tool up to the maximum admissible load (see type plate).
- The holding brake is intended for operation in dry, clean production halls (normal factory environment).

In case of strong generation of dirt around the holding brake, e.g. grinding dust, swarf, cooling agent or other liquid media, special protective measures are required.

• During normal operation the holding brake is to be so activated that it opens.

In all other operating conditions, power failure, emergency-stop, etc., the holding fixture activates and holds the piston rod or brakes the load. At a defect of the supply line to the holding fixture the load is secured.

- If the pressure is not sufficiently constant (e.g. "pressure hole" at the start of the lowering movements) a check valve must be installed in the compressed air supply of the valve.
- If impact noises occur during the opening of the holding brake due to the relatively high pressure, they can be suppressed with a throttle in the pressure line (connection 'L').
- The pressure room of the clamping head and its pressure feed line must always be vented.

Electrical activation

The following applies:

- Two signals can be taken by means of proximity switches.
- A safe state exists when signal 'A' (load secured) is active.
 This signal must be processed and displayed by the machine control.
- The function must be cyclically monitored, which happens suitably by the cyclical adjustment with signal 'B' (clamping released).
- Downward travel is only possible if signal 'B' is active after pressure is applied to the holding fixture (clamping released).
 The control must be programmed in such a way that when this signal is missing, upward travel takes place automatically until signal 'B' (clamping released) appears.



3.7 Activation and pressure control

3.7.1 Activation according to dynamic pressure method

If the working piston meets a counterforce during the fast approach stroke, it stops and the dynamic pressure acting on the piston surface falls. The power stroke valve switches and the intensifier piston is impinged with compressed air.

The changeover time is controlled and adjusted with the control throttle X.

The drive is actuated like a double-acting pneumatic cylinder, via an electrical, pneumatic or mechanical 4/2 or 5/2 directional control valve or via a 4/3 or 5/3 directional control valve.

The drive must be switched to initial position before changing over to the fast approach stroke.

3.7.2 Design principles of activation

A distance-dependent external power stroke switch is recommendable:

- For a piston rod working upwards.
- In the case of a heavy tool weight.
- In the case of fast approach stroke travel that is interrupted on account of the application (e.g. for fixing in place a spring-loaded holding-down clamp).
- If the control throttle 'X' cannot be adjusted for reasons of installation.

An external power stroke release with an electrical release signal is recommendable:

• If the power stroke release can accidentally be activated with the control throttle 'X' due to interference contours in the working area.

When depressurizing a pressure valve (pneumatic spring), the following applies:

• When the forward stroke connection and back stroke connection are switched, the compressed air supply of the pneumatic spring must also be turned off.

Measuring connection and control connection

The oil pressure proportional to the press force is present on the measuring connection and control connection.

This can be displayed, for example, by connecting a pressure gauge or used via transmission to a pressure switch for generating a switching pulse.



4 Technical data

4.1 Type sheet and data sheet

For technical data and installation dimensions see data sheet. www.tox.com

4.2 General environmental conditions

 The TOX[®] Powerpackage is protected against the penetration of liquids and contamination from the environment by means of seals, strippers and mufflers. However, the penetration of foreign substances during the use of dusty or strongly contaminated environment cannot be completely excluded.

The damages resulting from contamination during operation are not covered by warranty regulations.

- The penetration of water or other corrosive liquids must be prevented.
- No guarantee for use in environments with strongly corrosive environmental conditions such as increased salt content (maritime climate), cleaning with corrosive cleaning agents, or the use of high-pressure cleaners.
 If the drives are used in a corrosive environment, TOX[®] PRESSOTECHNIK can supply drives in corrosion-protected design.
- The specified maximum admissible environmental temperature must not be exceeded to prevent damages to the sealing system and inadmissible expansion in the hydraulic system.
 See Ambient temperature, Page 47.
- The specified particle size and moisture for compressed air is to be adhered to.

See Compressed air quality and pneumatic connection, Page 48.

4.3 Ambient temperature

Approved ambient temperature: 10 °C to 60 °C.



4.4 Compressed air quality and pneumatic connection

The following is required:

• Filtered and dried compressed air

Lightly oiled compressed air is permitted.

Compressed air quality (according to DIN ISO 8573-1):

Solids		Water dew point		Maximum Oil content	
Class	[µm]	Class	[°C]	Class	[mg/m3]
5	40	4	3	3	1

4.4.1 Pneumatic connection, air pressure, oil pressure

See data sheet. www.tox.com

- Default setting: P_{EL} 0.8 bar
- Minimum supply pressure of pressure valve: P_{min} = 2.5 bar.

4.5 Tightening torques

4.5.1 Tightening torques for flange mounting the drive

Prescribed tightening torques for fastening screws of property class ISO 4762-12.9:

Thread size	Torque
M 6	17 Nm
M 8	40 Nm
M 10	80 Nm
M 12	135 Nm
M 16	340 Nm
M 20	660 Nm
M 24	1,130 Nm
M 30	2,250 Nm



4.5.2 Tightening torques on the piston rod

Tool coupling	Piston rod thread	Tightening torque
ZWK		
ZWK 001	M12 x 1.5	10 Nm
ZWK 002	M16 x 1.5	15 Nm
ZWK 004	M22 x 2.0	40 Nm
ZWK 008	M30 x 2.0	180 Nm
ZWK 015	M30 x 2.0	210 Nm
ZWK 030	M39 x 2.0	230 Nm
ZWK 050	M42 x 2.0	290 Nm
ZWK 075	M64 x 2.0	500 Nm
ZWK 200	M80 x 2.0	500 Nm

4.5.3 Tightening torques for total stroke adjustment (option)




Fig. 16 Tightening torques for setscrews

Thread size	Torque
M 5	5 Nm
M 8	18 Nm
M 10	32 Nm



4.5.4 Tightening torques of pneumatic screw fittings on the Powerpackage

The specified tightening torques only apply to pneumatic screw fittings on the Powerpackage.

Connecting thread	Tightening torque
1/8"	10 Nm
1/4"	15 Nm
3/8"	25 Nm
1/2"	30 Nm

4.5.5 Tightening torques for hydraulic screwings

Connecting thread	Tightening torque
3/8"	35 Nm
1/2"	60 Nm
3/4"	90 Nm
1"	140 Nm

4.5.6 Tightening torque of hydrosplit coupling ZHK

Hydrosplit coupling ZHK, manually switchable

Туре	Screws Pos. 5	Screws Pos. 6	Screws Pos. 7	Hydraulic lineconnection
ZHK 018.000	M 8 / 27 Nm	M 10 / 60 Nm	10 Nm	G 3/4"
ZHK 020.000	M 8 / 27 Nm	M 10 / 60 Nm	10 Nm	G 1"
ZHK 042.000	M 20 / 425 Nm	M 20 / 425 Nm	20 Nm	SAE 2

Type: ZHK 018.000, ZHK 020.000, ZHK 042.000

Tab. 5 Tightening torques, Hydraulic line connection



Hydrosplit coupling ZHK, with electrically switchable valve

Type: ZHK 018.001, ZHK 020.001

Туре	Screws Pos. 5	Screws Pos. 6	Screws Pos. 7	Hydraulic lineconnection
ZHK 018.001	M 8 / 27 Nm	M 10 / 60 Nm	10 Nm	G 3/4"
ZHK 020.001	M 8 / 27 Nm	M 10 / 60 Nm	10 Nm	G 1"

Tab. 6 Tightening torques, Hydraulic line connection

4.6 Press force table

Press force table see separate document.

4.7 Specification for hydraulic oil

The following oils are approved for standard application:

- Hydraulic oil HLP32 (according to DIN 51524-2), filtered < 5µm, load rating > 30 N/mm2
- Food grade oil Klüber Summit HySyn FG 32

The following hydraulic oils are approved with limitations for standard application:

- Hydraulic oil UCON™ LB-165
- Synthetic oil ISOTEX 46
- Synthetic oil Envolubric PC 46 NWL
- The use of hydraulic oils that have not been approved as standard can lead to an increase of maintenance intervals due to an increased intake of air.
- The use of hydraulic oils that have not been approved as standard can reduce the lubrication capacity lower than for HLP32 hydraulic oils. This can lead to a shorter lifetime of seals.
- Some sealing materials in case of hydraulic oils not approved as standard tend towards increased swelling and therefore to a reduced lifetime of the seals.



NOTE

Loss of warranty in case of the use of non-approved hydraulic oils!

Due to the negative effects on maintenance intervals, swelling behavior and lifetime of the seals in case of the use of hydraulic oils that have not been approved as standard, the granted warranty becomes extinct.

- → Use hydraulic oils that have bee approved by TOX[®] PRESSOTECHNIK as standard.
- ➔ Use other hydraulic oils only after the express approval of TOX[®] PRESSOTECHNIK.
- ➔ Do not mix different hydraulic oils. Negative effects such as flocculation cannot be excluded.



5 Transport and storage

5.1 Safety during transport

\land WARNING

Hazard from suspended loads!

Severe crushing, impacts and serious accidents as a result of improper transportation and falling load!

- → Only use lifting gear that is appropriate and in perfect technical condition, as well as load attachment devices with an adequate safe working load.
- → Never stand or work under suspended loads.
- → Make sure that that no person is in the danger area.
- → When transporting and setting down, make sure that no parts of the body become jammed.
- → Wear suitable personal protective equipment (e.g. safety boots).

A CAUTION

Injury from toppling and falling products!

- ➔ Secure product from toppling, falling and accidentally moving.
- The transportation may only be carried out by authorized personnel.
- The product may only be transported with empty liquid containers.
- The product may only be transported with the transport pallet or transport device provided.
- The product may only be lifted with suitable lifting devices at suitable lifting points.

See Safety symbols.

- Note the weight of the product. See technical data sheet.
- Note the center of gravity of the product. See general arrangement drawing.



5.2 Lifting device

Depending on the size of the drive, the flange cover at the rear is provided with threaded bore holes for ring bolts for hoisting.

Risk of impact and crushing due to products swivelling out!

Severe impacts, crushing, and serious accidents as a result of the product rotating and swiveling out.

- → Pay attention to the center of gravity and pivot point.
- → Establish a V-shaped suspension connection in the center of gravity between the ring bolts.
- ➔ If there are no threaded holes, suspend the ring bolt between the working part and intensifier.
- → Lift up the product carefully.

5.3 Temporary storages

- Use original packaging.
- Make sure that all connections and threads are covered to prevent dust ingress and shocks.
- Store the product only in closed, dry, dust-free and dirt-free rooms at room temperature.



5.4 Dispatch for repair

To dispatch the product for repair to TOX[®] PRESSOTECHNIK, please proceed as follows:

- Fill in the "Accompanying repair form". This we supply in the service sector on our website or upon request via e-mail.
- Send us the completed form via e-mail.
- Then you will receive the shipping documents from us via e-mail.
- Send us the product with the shipping documents and a copy of the "Accompanying repair form".

For contact data see Contact and source of supply, Page 12 or www.tox.com.



6 Installation

6.1 Safety during installation

The installation may only be carried out by trained and authorized personnel.

A DANGER

Electrical hazards in case of contact with live parts!

Electric shock, burns or death in case of contact with live parts!

- → Have all work on the electrical equipment performed by an electrician.
- ➔ Disconnect power supply.
- → Wait for residual energy to disspate safely (at least 3 minutes).

A WARNING

Ejecting parts and compressed air from compressed air conducting lines! Serious injuries to eyes and body cavities!

- → Always connect and disconnect lines without pressure.
- → Pay attention to maximum permitted pressures.
- → Wear individual protective equipment.

Tripping points from laid supply lines!

Injuries from tripping and falling!


- → Avoid tripping points when setting up.
- → Mark unavoidable tripping points with warning sign.



6.2 Installing drive

- Screws of the strength class : 12.9 (in accordance with ISO 4762)
- Torque wrench
- WARNING! Risk of crushing! Attach lifting device (ring bolts) and use appropriate lifting gear.
 Place and align drive on the fastening element provided.
- 2. Tighten screws, observe torques while doing so. See Tightening torques, Page 48.





6.3 Connecting and separating hydrosplit coupling

Fig. 17 Hydrosplit coupling

Туре	Screws Pos. 5	Screws Pos. 6	Screws Pos. 7	Hydraulic lineconnection
ZHK 018.000	M 8 / 27 Nm	M 10 / 60 Nm	10 Nm	G 3/4"
ZHK 020.000	M 8 / 27 Nm	M 10 / 60 Nm	10 Nm	G 1"
ZHK 042.000	M 20 / 425 Nm	M 20 / 425 Nm	20 Nm	SAE 2

Tab. 7 Tightening torques, Hydraulic line connection

Hydrosplit coupling installing and connecting

- 1. Unite coupling part hose and coupling part installer.
- 2. Tighten fastening screws housing (see table tightening torques).
- 3. Open valve/screw.



Hydrosplit coupling separating

NOTE

Seal damage due to overpressure

During the separating of the hydrosplit coupling overpressure can be generated in the coupling which might damage the seals.

- → Before dividing the hydrosplit coupling you must first close the coupling part on the hose side.
- 1. Close the valve/screw on the hose side.
- 2. Close the valve/screw on the device side.
- 3. Loosen the housing fastening screws.
- 4. Loosen coupling part of hose and coupling part of intensifier.



6.4 Installing hydraulic hose lines

If hydraulic components are installed in the system, the requirements and national legal provisions must be adhered to.


For example, in Germany the following requirements are stated according to BG-Regulation 237



For the direct mounting of hydraulic components, only hydraulic screw fittings with elastomer flat seals are permitted to be used. Other sealing, such as compression joints or radial seals are not admissible.

Installer guideline

- Avoidance of torsion.
- Adherence to the admissible bending radius.
- Avoidance of abrasion, fretting points and kinking.
- Avoidance of tensile and crushing stress.
- Consideration of the effect of temperatures.
- Consideration of vibrations.
- Prevention of whipping.
- Adherence to the specified max. admissible hydraulic pressure.
- Consideration of fire prevention measures.
- Avoidance of direct sunlight or UV rays.
- Shielding against adjacent heat sources.
- Do not use ozone-forming lamps (e.g. fluorescent lamps, mercury-vapor lamps), nor electric spark-discharging devices in close proximity.




- Fig. 18 Installer guideline
- \checkmark The system is switched pressureless and secured against restarting.
- → To be carried out by service personnel only.



6.5 Installing optional accessories

6.5.1 Installing electronic pressure switch (ZDO)



Material required:

- Electronic pressure switch (ZDO)
- Assembly holder (ZMP)
- High-pressure measuring hose (ZHM)

NOTE

Air trapped in the connecting line!

Air could get into the high pressure chamber, impair the working process and distort the measuring result.

→ Fill connecting line with oil and vent.



- Make sure that the system is depressurized and disconnected from the power supply.
- Observe the tightening torques.
 See Tightening torques, Page 48.
- 1. Install assembly holder of pressure switch on the drive. Make sure that display and operating elements are easily accessible.
- 2. Fasten the pressure switch in the assembly holder.
- 3. Install high pressure hose on the pressure switch and on the high pressure measuring connection.
- 4. Connect cable of the pressure switch on the control system according to circuit diagram.

See pressure switch ZDO operating manual.



6.5.2 Installing and setting position sensors of stroke monitoring for forward and return stroke (ZHU)




Fig. 19 Installing position sensors for stroke monitoring for forward and return stroke


- Magnet-sensitive proximity switch with LED (ZHS 001.001)
- Holding angle for proximity switch
- Cable box
- 1. Installing holding angle.
- 2. Installing proximity switch.
- 3. Connect the proximity switch to the control. See circuit diagram.



Setting the position sensors

- ✓ Proximity switches are connected.
- ✓ Working piston in home position.
- 1. Push the proximity switch from the edge of the cylinder to the first switch-on point.
 - \triangleright The LED lights up.
- 2. Mark the edge of the proximity switch on the cylinder.
- 3. Push the proximity switch further to the switch-off point.
 - \triangleright The LED switches off.
- Push the proximity switch back to the 2nd switch-on point.
 ▷ The LED lights up.
- 5. Mark the edge of the proximity switch on the cylinder.
- 6. Position and fix the proximity switch between the two markings.





6.5.3 Installing the external linear position sensor (ZHW)

Material required:

1

Prerequisite for the installation of the external linear position sensor:

- TOX[®] Powerpackage type line-Q, line-X or RZS
- 20 mm stroke reduction either positioned inside in the Powerpackage or
- positioned outside the tool
- Linear position sensor (ZHW)
- Holding angle for linear position sensor


 \checkmark The operating manual of the linear position sensor is available.

NOTE

Risk of damage to the device due to incorrect installation and connection!

- The specifications of the operating manual of the manufacturer are to be adhered to.
- 1. Installing holding angle.
- 2. Insert the linear position sensor into the holding angle. Ensure that the position sensing system with contact bears against the front flange.
- 3. Adjust position sensing system. Ensure that for ZHW 002/004/008/015 there is a distance between the front flange and front edge of the travel sensor of 2 +/-0.05 mm, and for ZHW 030 a distance between the front flange and front edge of the travel sensor 14 +/-0.05 mm.
- 4. Ensure the parallel alignment of the position sensing system to the longitudinal axis.
- 5. Fix the position sensing system with set screws to the tension rods to prevent it from shifting. Tightening torque: 2 Nm.
- 6. Secure the set screws with the hexagon nuts and with safeguarding lacquer.
- Connect the position sensing system to the control. See circuit diagram and operating instructions of the position sensing system.





6.5.4 Installing pressure control in the power stroke line (ZDK)


Fig. 20 Installing pressure control in the power stroke line (assembly ZDK)

- Manual pressure regulator (ZDK)
- Screw plug with collar, size M 5 (laterally on power stroke valve next to connection [12])



- For connections see Pressure control in the power stroke line (assembly ZDK) (optional).
- 1. Remove the screw plug on the control connection [12].
 - \triangleright The lower positioned M 5 threaded hole is set free.
- 2. Remove the M5 screw plug from the par position.
- 3. Screw the M 5 screw plug fully into the lower positioned M 5 threaded hole of the control connection [12].
 - ▷ The M 5 threaded hole in power stroke valve is closed.
- 4. Connect control connection [12] on the power stroke valve to output of fast approach stroke [4.1] or connection [4.4] on the pressure regulator. In addition, install hose line and seal.
- 5. Install pressure regulator on power stroke input [1].
- 6. When installing a proportional pressure regulator, connect it to the control. See data sheet, or circuit diagram.





6.5.5 Installing proportional pressure control valve in the power stroke line

Fig. 21 Installing proportional pressure control valve in the power stroke line

Material required:

- Proportional pressure control valve
- Screw plug with collar, size M 5 (laterally on power stroke valve next to connection [12])
- For connections see Pressure control in the power stroke line (assembly ZDK) (optional).
- 1. Remove the screw plug from the control connection [12] and screw the M 5 screw plug with collar fully in.
 - \triangleright Bore hole in power stroke valve is closed.
- 2. Connect the control connection [12] on the power stroke valve with output of fast approach stroke [4.1] or connection [4.4] on the proportional pressure control valve. In addition, install hose line and seal.
- 3. Install pressure regulator on power stroke input [1].
- 4. When installing a proportional pressure control valve, connect it to the control.

See data sheet, or circuit diagram.



6.5.6 Installing external power stroke connection (ZKHZ)






Fig. 22 Installing external power stroke connection (ZKHZ)

- Electrical switching valve power stroke switch (ZKHZ)
- Screw plug
- For connections see External power stroke switch (assembly ZKHZ) (optional).
- 1. Disassemble control throttle 'X'.
- 2. Connect the control throttle 'X' connection to screw plug.
- 3. Install power stroke switch to connection of the power stroke valve [14].
- 4. Connect the power stroke switch to permanent compressed air supply.
- 5. Connect the power stroke connection to the control. See circuit diagram.




6.5.7 Installing external power stroke release (ZKHF) and power stroke deactivation (ZKHD)





- Electrical switching valve power stroke release (ZKHF) and power stroke deactivation (ZKHD)
- Pneumatic OR valve
- For connections see External power stroke deactivation (assembly ZKHD) (optional).
- 1. Install switching valve power stroke release and power stroke deactivation with OR valve on control connection [14].
- 2. Connect line of the control throttle 'X' to the OR valve.
- For the external power stroke release (ZKHF) connect the pneumatic input [3] of the switching valve to the permanent compressed air supply.
 OR -
- 4. For the external power stroke deactivation (ZKHD) connect the pneumatic input [1] of the switching valve to the permanent compressed air supply.





6.5.8 Preparing external power stroke supply

Fig. 24 Preparing external power stroke supply

- Screw plug M 5 with collar (laterally on power stroke valve next to connection [12])
- ✓ For connections see External power stroke supply (optional).
- 1. Remove the screw plug from the control connection [12] and screw the M 5 screw plug with collar fully in.
 - \triangleright Bore hole in power stroke value is closed.
- 2. Connect control connection [12] on the power stroke valve to output of fast approach stroke [4.1]. In addition, install hose line and seal.
- 3. Install external power stroke supply on power stroke input [1].



6.5.9 Installing the stroke frequency optimization (ZHO)

Installing the stroke frequency optimization (ZHO) for drive with integrated power stroke valve




Fig. 25 Installing the stroke frequency optimization ZHO

- Stroke frequency optimization (ZHO) for drive with integrated power stroke valve
- Pneumatic supply line including all series-connected valves in the size fitting to the connections.
- 1. Remove circlip and plug.
- 2. Remove the valve slide.
- 3. Install the plug and circlip.
- 4. Installing the stroke frequency optimization (ZHO).



Installing the stroke frequency optimization (ZHO) for drive with external power stroke valve





Fig. 26 Installing the stroke frequency optimization ZHO

- Installing the stroke frequency optimization (ZHO) for drive with external power stroke valve
- Pneumatic supply line including all series-connected valves in the size fitting to the connections.
- 1. Dismantle the existing external power stroke valve.
- 2. Install the stroke frequency optimization (ZHO).





6.5.10 Installing the speed reduction for power stroke venting

Fig. 27 Installing the speed reduction for power stroke venting

- Adjustable exhaust air damper (ZD)
- 1. Install the exhaust throttle between the power stroke valve output [3] and the muffler.
- 2. Connect the compressed air supply connections.
- Set the exhaust air damper. See Set the speed ratio between power stroke and power stroke venting (optional), Page 79.



6.5.11 Installing tool coupling (ZWK)




Fig. 28 Installing tool coupling (ZWK)

The thread at the end of the piston rod is intended for the installation of a tool holding fixture or a tool.

- Tool holding fixture (ZWK) or tool
- Low-strength screw locking compound (e.g. Loctite 222)
- Lubricating grease (Klübersynth UH1 14-151 or a technically comparable one)
- Technical data, dimensions are observed.
 See data sheet, or type sheet at www.tox.com.
- Install the tool holding fixture on the thread of the working piston. Observe tightening torques.
 See Tightening torques on the piston rod, Page 49.
- 2. Secure the tool holding fixture screw locking compound.
- 3. Wet the contact surface between the holding tray and tool holding fixture with lubricating grease.
- 4. Install the holding tray on the ram or on the tool plate.



7 Commissioning

7.1 Safety during the commissioning

The commissioning may only be carried out by trained and authorized personnel.

The following applies:

- Make sure that that no persons are located within the danger area of the machine.
- Observe technical data and limit values. See Technical data.

7.2 Requirements for the commissioning

This incomplete machine may not be commissioned until it has been ascertained that the incomplete machine in which the component is to be installed complies with the requirements of the Machinery Directive (2006/42/EC).

The requirements are:

- Safety devices of the machine are fully assembled and functional.
- The drive is fully assembled.
- All supply lines are connected.
- The required compressed air qualities and connection values are present.
- Sufficient pieceparts and material are available.

7.2.1 Measuring connection and control connection

The oil pressure proportional to the press force is present on the measuring connection and control connection.

This can be displayed, for example, by connecting a pressure gauge or used via transmission to a pressure switch for generating a switching pulse.



7.3 Setting control throttle 'X'

The control throttle 'X' is used to set the timing of the switchover from fast approach stroke to power stroke, and must be readjusted for each application (e.g. tool weight drawing/pressing). The effect of the control throttle 'X' is influenced by the system pressure and by setting an optional fast approach stroke throttle.




Fig. 29 Setting control throttle 'X'

- ✓ Working piston is retracted.
- ✓ Compressed air supply is switched on.
- 1. Close control throttle 'X' when piston is retracted and impinged by turning clockwise.
- 2. Extend working piston rod.
- 3. Open control throttle 'X' slowly by turning counterclockwise until the power stroke is noticeably activated on meeting a counterforce. Opening the control throttle 'X' further causes the power stroke to be activated earlier.



7.4 Setting speed ratio of return stroke to fast approach stroke

The speed of the working piston in the fast approach stroke and return stroke can be set with external exhaust air dampers on the forward stroke and return stroke. The exhaust air dampers may have to be retrofitted.

Necessary speed ratio	
Hy	raulic cylinder HZL
•	Forward stroke equally fast or up to max. 20% faster than the return stroke
Hyo	raulic cylinder HZL with total stroke adjustment
•	Forward stroke equally fast as return stroke
Wo	king part X-AT, AT
•	Return stroke equally fast or faster than the forward stroke
Wo	king part AT with total stroke adjustment
•	Forward stroke equally fast as return stroke

Tab. 8 Necessary speed ratio



A visual check of the speeds is generally sufficient.

- 1. Set speed ratio according to the specifications.
- 2. Perform test and check the speed visually.

7.5 Set the speed ratio between power stroke and power stroke venting (optional)

At throttled power stroke speed

Necessary speed ratio between power stroke and power stroke venting

- Power stroke speed equal to the return stroke speed of the intensifier piston or
- Power stroke speed faster than the return stroke speed of the intensifier piston

Tab. 9 Necessary speed ratio

A visual

A visual check of the speeds is generally sufficient.

- 1. Set speed ratio according to the specifications.
- 2. Perform test and check the speed visually.



7.6 Commissioning hydrosplit coupling ZHK

7.6.1 Commissioning hydrosplit coupling (manually switchable)

Type: ZHK 018.000, ZHK 020.000, ZHK 042.000



Before the separating of the hydrosplit coupling ZHK, first the hose-side coupling part must be closed, otherwise overpressure can be generated in the coupling which might damage the seals.

Maximum admissible operating pressure: 400 bar.

Tightening torques, for hydraulic line connection see Tightening torque of hydrosplit coupling ZHK, Page 50.



7.6.2 Commissioning hydrosplit coupling (with electrically switchable valve)

Before the separating of the hydrosplit coupling ZHK, first the hose-side coupling part must be closed, otherwise overpressure can be generated in the coupling which might damage the seals.

Maximum admissible operating pressure: 400 bar.

Tightening torques, for hydraulic line connection see Tightening torque of hydrosplit coupling ZHK, Page 50.

Setting switching process of hydrosplit coupling with electrically switchable valve

Type: ZHK 018.001, ZHK 020.001

At the design of the control it is to be observed that the hydrosplit coupling ZHK is activated with a delay time of $d \ge 200$ ms earlier than the fast approach stroke. During the return stroke the hydrosplit coupling ZHK must remain open until the cylinder has again reached its final position.



Control plan X-AT, AT






Fig. 30 Control plan X-AT, AT hydrosplit coupling ZHK

Control plan HZL





Signal sequence program



Pos	Designation	Pos	Designation
Z 1	Cylinder 1	SP	Working cycle of drive
ZHK 1	Switch position for cylinder 1	0	Signal off
V 1.1	Valve	1	Signal on
V 1.2	Valve	v	Forward stroke
Z 2	Cylinder 2	r	Return stroke
ZHK 2	Switch position for cylinder 2	k	Power stroke
V 2.1	Valve	d	Delay time (≥ 200 ms)
V 2.2	Valve		





A forward or return stroke of the working cylinder at a closed hydrosplit coupling ZHK is not admissible.

- → Observe the enclosed control plans of the KT-system.
- The hydrosplit coupling cannot be opened or closed during the power stroke.
- → The coupling is closed in a pressureless state.

Manual actuation




Fig. 31 Manual actuation

The manual actuation of the valve must be switched off during normal operation of the KT system (switch in position '0'). If the manual actuation is activated (switch in position 'I'), the electric signal of the control is not taken into consideration, the hydrosplit coupling ZHK is always switched open.



7.7 Setting total length of stroke (optional)

In the series with total stroke adjustment, the length of the total stroke can be adjusted independently of the length of the power stroke and the length of the cylinder.





Fig. 32 Setting total length of stroke

- 1. Dismantle the protective covering on the working piston.
- 2. Loosen clamping screws.
- 3. Screw in or unscrew the adjustment sleeve until the desired total stroke length is adjusted. The adjustment path can be read on a scale on the adjustment sleeve.
 - ▷ Unscrew adjustment sleeve: The total stroke length is extended.
 - Screw in adjustment sleeve: The total stroke length is shortened.
- 4. Tighten clamping screws. See Tightening torques, Page 48.
- 5. Install the protective covering.





7.8 Setting the (ZED) damping (optional)


Fig. 33 Setting (ZED) damping (optional)

The integrated damping function allows a selectable, adjustable constant speed of the working piston during the fast approach stroke and power stroke, independent of the respective working forces. This makes it is possible to almost fully compensate the acceleration of the working piston when the counterforce is removed (during punching) or also a stick-slipeffect (during pressing in.

At the same setting of the flow control valve the speeds of the working piston during the fast approach stroke and power stroke are almost constant. This allows a very soft placement on the piece part.



Function sequence and switching states



The damping is set on the flow control valve (1V61 or 1V62). The electrically switchable solenoid valve (1V8) makes individual activation and deactivation of damping possible. With the standard stroke monitoring on the working piston the time can be specified at which damping is to be activated.

- Fast approach stroke
 - For a fast approach stroke the solenoid valve (1V8) must be switched electrically, so the oil can flow unrestricted.
- Activation of damping during the fast approach stroke for a soft placement on the piece part (Soft Touch)

Activation of damping during the fast approach stroke.

- Damping can be activated already via an external distance signal.
- For a smooth contact with the piece part, the response time of the solenoid valve (1V8) listed in the data sheet and the response distance traveled by the working piston during this time must be taken into consideration.
- Solenoid valve (1V8) switched off (0-active), the oil flows through the flow control valve (1V61 or 1V62) and the damping effect begins.



- Activation of damping during the power stroke
 - The power stroke must, for example, be activated via an external distance signal electrically on valve (1V6).
 - Solenoid valve (1V8) switched off (0-active), so the oil flows through the flow control valve (1V61 or 1V62) and the damping effect begins.
- Return stroke
 - For a fast return stroke a check valve is integrated in the solenoid valve (1V8) so the oil can flow unrestricted independent of the switching state.
- Emergency off
 - When an emergency stop is triggered the solenoid valve (1V8) is switched off. During the subsequent back stroke into the home position the oil is conveyed back via the installed check valve.
- → Set damping with the manual flow control valve. For this, turn the set screw open or closed.

- OR -

Set damping with the electrical proportional flow control valve.




7.9 Setting cutting impact damping (ZSD) (optional)

Cutting impact damping is set in 2 steps:

- Setting the total length of stroke, Page 85.
- Setting the damping effect, Page 89.

7.9.1 Setting the damping effect





The total stroke is set.
 See Setting total length of stroke (optional), Page 85.

WARNING

Bursting, flying parts and ejecting oil due to excessive oil pressure!

Severest injuries to eyes, body cavities and all over the body!

- → The oil pressure at the cutting impact damping (ZSD) must not exceed 450 bar at closed damping. Maximum admissible is 450 bar.
- → Wear individual protective equipment.
- 1. Loosen the counter nut on the outer thread of the control pin.
- 2. Set the damping effect with the control pin. Turn to the right: Increase the damping effect. Turn to the left: Reduce the damping effect.
- 3. Take note that a quarter turn can result in a perceptible change of the damping. Set the damping stepwise.
 - \triangleright The damping effect is set.
- 4. Fasten the counter nut.



7.10 Setting the proximity sensors of the holding brake (ZSL) (optional)






Fig. 34 Setting the proximity sensors of the holding brake

- 1 Holding fixture for sensor "Lock loos- 2 ened" [B]
- 3 "Loosen" pressure connection [L] 4
- Holding fixture for sensor "Load secured" [A]
- "Pressure compensation" connection [T]

Control plan ZSL






Material required:

 2 Proximity switch, inductive: External thread: M 12 x 1 / Ø 12 mm Closing function Nominal distance: 2 mm, can be installed flush





The connections are marked permanently. The position of the connections can vary depending on the model.





NOTE

Destruction of sensors!

Sensors that are screwed too deep into the holding fixture for sensor "Lock loosened" [B], are destroyed when the locking head is activated!

- ➔ Ensure that the sensors are seated correctly.
- ➔ Observe the operating instructions of the holding brake.
- 1. Supply the holding brake with compressed air.
- 2. Secure the adjustment sleeve on the holding fixture for sensor "Load secured" [A] and ensure that it cannot turn.
- 3. Screw the sensor "Load secured" [A] in only until it lights up. Ensure that it is not screwed in deeper.
- 4. Turn off the holding brake with compressed air.
- 5. Secure the adjustment sleeve on the sensor "Lock loosened" [B] and ensure that it cannot turn.
- 6. Screw the sensor "Lock loosened" [B] in only until it lights up. Ensure that it is not screwed in deeper.
- 7. Check whether the turned-off compressed air "Load secured" [A] is lit.
 - Sensor "Load secured" [A] is lit: WARNING! Damage to sensor! Sensor is screwed in too deep.
 Readjust sensor "Lock loosened" [B].
- 8. Pull sensors back 0.5 mm to 1 mm.
- 9. Fix the sensors with the counter nut.



7.11 Check the holding force of the holding brake

In the installed state the holding force of the holding brake must have a safety reserve of at least the 1.5-fold of the existing load.

Risk of injury due to a non-functioning holding brake!

- → Check the holding brake at regular intervals!
- → Observe the operating instructions of the holding brake.
- ✓ The holding brake is closed, the piston rod is secured.

WARNING

Risk of crushing due to dropping piston rod!

Ensure that contact with moving machine parts is not possible during the safety test.

If necessary, program an automatic test operation. If necessary, provide a two-hand operation.

- → Check the holding force of the holding brake. See the operating instructions of the holding brake.
- ▶ The piston rod slides through: The holding brake brake is NOK.
- ▶ The piston rod does not slide through: The holding brake brake is OK.



8 Operation

8.1 Safety in operation

Dangerous machine movements!

Serious contusions and injuries!

→ Make sure that that no persons are located in the danger area during operation.

Noise during operation!

Hearing impairment!

→ Wear individual protective equipment.

A CAUTION

Hazard from flying parts!

Injuries to eyes and body cavities!

→ Wear individual protective equipment.



8.2 Requirements for operation

- The safety devices of the entire machine are properly assembled and functional.
- All components are properly maintained, clean and without damage.
- Supply connections, communication and control connections, material or media hoses are installed properly. The permissible values are complied with.
- The main switch of the machine is switched on.
- Compressed air supply is open.
- The fault message on the machine are acknowledged.
- There are no persons are located in the danger area.
- A visual inspection is carried out, especially:
 - Position of the oil level indicator when the working piston is retracted (oil level indicator flush with the surface of the cylinder).
 - No objects in the working area.

8.3 Operating drive

The operation depends on:

- Intended purpose
- Control system
- Operating elements
- Safety equipment
- Tooling and accessories



9 Troubleshooting

9.1 Safety during troubleshooting

Troubleshooting may only be carried out by trained and authorized personnel.

• Make sure that that no persons are located within the danger area of the machine.



9.2	Searching for causes	of fault on the Powerpackage
-----	----------------------	------------------------------

Fault	Possible cause	Measure	
Piston rod does not extend.	Tool jams. Guiding columns are jammed.	Mechanically decouple the Powerpackage and check ease of movement by extending and retracting.	
	Air pressure too low (only for assembly direction from the bottom to the top).	Check air pressure and increase if nec- essary.	
	Main control valve does not switch.	Check main control valve. Contact authorized service personnel.	
	Unlockable check valves (optional equipment) do not open.	Check non-return valves. Contact authorized service personnel.	
	Faulty pneumatic hose.	Check the compressed air supply. Contact authorized service personnel.	
No execution of power stroke.	Insufficient air pressure.	Increase air pressure.	
Press force not reached.	Compressed air setting on pressure regulator in the power stroke line (optional) is too low.	Increase air pressure in power stroke line.	
	Pneumatic spring pressure setting is too high or the pneumatic spring is	Check compressed air supply of the pneumatic spring.	
	faulty.	Contact authorized service personnel.	
	Oil level is too low.	Checking oil level, Page 104.	
	Air is trapped in the hydraulic oil system.	Refilling oil and venting drive, Page 105.	
	Power stroke valve is faulty.	Contact authorized service personnel.	
	Control throttle 'X' incorrectly set, over- loaded.	Setting control throttle 'X', Page 78.	
	No air pressure in home position.	Impinge the return stroke with air pres- sure before initiating the fast approach stroke.	
Power stroke not triggered with very short fast approach stroke (only for type Q-S, X-S, S, EL with hydraulic end position cushioning ZHD)	The fast approach distance traveled is too short. Required: min. 8 mm.	Set sufficient travel for fast approach stroke before the power stroke is switched on.	
Piston rod does not retract.	Tool jams. Guiding columns are jammed.	Mechanically decouple the Powerpackage and check ease of movement by extending and retracting.	
	Insufficient air pressure.	Check air pressure and increase if nec- essary.	
	Main control valve does not switch.	Check main control valve. Contact authorized service personnel.	
	Unlockable check valves (optional equipment) do not open.	Check non-return valves.	
		Contact authorized service personnel.	
	Pneumatic hose is faulty.	Check the compressed air supply. Contact authorized service personnel.	
	Tool is too heavy for return stroke force.	Increase return stroke pressure.	
		Use additional return stroke cylinders.	
	Changeover signal for return stroke is not present.	Check electrical switching signal (e.g. for ZHU, ZHW, ZDO).	
		Contact authorized service personnel.	
	Power stroke valve is faulty.	Contact authorized service personnel.	
	Pneumatic spring pressure regulator or pressure gauge pneumatic spring is	Check the compressed air pressure on the pressure gauge.	
	faulty.	Contact authorized service personnel.	



Fault	Possible cause	Measure	
Frequent refilling of hydraulic oil is necessary.	Speed ratio of fast approach stroke to return stroke is set incorrectly.	Setting speed ratio of return stroke to fast approach stroke, Page 79.	
		Contact authorized service personnel.	
	Speed ratio of power stroke and power stroke venting is set incorrectly.	Set the speed ratio between power stroke and power stroke venting (op- tional), Page 79.	
		Contact authorized service personnel.	
	Pneumatic supply insufficient. Cross- section of hose, size of connectors, switching valves, maintenance unit are too small.	Observe predefined connections sizes and cross-sections. See Datasheet.	
	Powerpackage is not fully vented.	Refilling oil and venting drive, Page 105.	
	Oil level after oil filling is not lowered.	Lowering of oil level, Page 118.	
	The HP measuring connection, vent screw or oil filling nipple is leaky or faulty.	Contact authorized service personnel.	
	Seals are damaged.	Contact authorized service personnel.	



Maintenance table of Powerpackage

The specified intervals are only approximate values. Depending on the area of application, the actual values may differ from the guide values.

Maintenance cycle	Additional information		
according to counter (flexible)	10.5	Refilling oil and venting drive	
	10.6.1	Refilling oil and venting drive with integrated damping function ZED	
	10.6.2	Refilling oil and venting drive with cutting impact damping ZSD	
	10.8	Check hydraulic hose lines	
Weekly	10.4	Checking oil level	
Half-yearly	10.10	Check the holding force of the holding brake	
6 years	10.9	Replacing hydraulic hoses	



10 Maintenance

10.1 General information

Maintenance may only be carried out by trained and authorized personnel. The following applies:

- Observe maintenance intervals if present and stipulated.
- Maintenance intervals may vary from the stipulated maintenance intervals. The maintenance intervals may have to be verified with the manufacturer if necessary.
- Perform only maintenance work that is described in this manual.
- Inform operating personnel before starting repair work.
- Appoint a supervisor.

10.2 Safety during maintenance

\Lambda DANGER

Electrical hazards in case of contact with live parts!

Electric shock, burns or death in case of contact with live parts!

- → Have all work on the electrical equipment performed by an electrician.
- ➔ Disconnect power supply.
- ➔ Wait for residual energy to disspate safely (at least 3 minutes).

WARNING

Hot surfaces on the drive and on the control box!

Injuries from burns!

→ Allow hot surfaces and motors to cool down before touching them.

Ejecting parts and compressed air from compressed air conducting lines! Serious injuries to eyes and body cavities!

- ➔ Always connect and disconnect lines without pressure.
- ➔ Pay attention to maximum permitted pressures.
- → Wear individual protective equipment.



Dangerous machine movements!

Serious contusions and injuries!

Make sure that that no persons are located in the danger area during operation.

NOTE

Incorrect cleaning agents or cleaning procedures, lack of corrosion protection!

Damage to machine components!

- Clean plastic parts such as panes (safety guard door, housing, etc.) and control elements with cotton cloths (smooth woven structure) and suitable cleaning agents (e.g. clear water and neutral rinsing liquid). Do not use scouring (abrasive) cleaning agents.
- → Only touch bare spots with gloves.
- ➔ For metallic surfaces use cleaning set, such as industrial cleaner (e.g. Loctite 7063, or Würth Montagekraftreiniger 0890 107), vacuum cleaner, dry cloth and brush.
- → After cleaning, protect bare outer surfaces from corrosion. Coat surfaces with a cloth slightly moistened with anticorrosive fluid.
- Keep inside surfaces, especially element-carrying parts, dry and free of grease.



10.3 Requirements for maintenance

10.3.1 Set system to maintenance position

Unless specified otherwise, before all maintenance work:

- 1. Retract the working piston.
 - ▷ The machine is in initial position (working piston retracted).
- 2. Install a restraint device if necessary.
- 3. Make sure that fast approach stroke and power stroke cannot be activated in maintenance position.
- 4. Make sure that return stroke is impinged with compressed air.
- 5. Make sure that the pressure valve (pneumatic spring) is impinged.
- 6. Make sure that unauthorized, accidental or unexpected starting up of the machine and initiation or dangerous movements due to latent energies are prevented.



10.4 Checking oil level





Fig. 36 Checking oil level

- System is in maintenance position.
 See Set system to maintenance position, Page 103.
- → Check needle of the oil level indicator.
- The needle of the oil level indicator is flush with the surface of the cylinder: Oil level is ok.
 - OR -
- The needle of the oil level indicator comes out: Oil must be refilled. See Refilling oil and venting drive, Page 105.





10.5 Refilling oil and venting drive

Fig. 37 Refilling oil and venting drive

Material required:

- Oil, filtered < 5 µm, load rating > 30 N/mm² (in accordance with DIN 51524-2 HLP DD32)
 If different special oils are used, see sticker.
- Oil pump ZP 20

Venting point according to installation position:

Installation position	Venting points	
Type X-ES	Venting points X-ES	
Vertical	Venting plate 5	
Hydrosplit coupling ZHK or hydraulic hose	Vent screws 7 at X-ES	
toward the top	HP measuring connection 3 at X-ES	
	Vent screws 8 of the hydrosplit coupling ZHK	

Installation position	Venting points
Vertical	Vent screws 7 at X-ES
Hydrosplit coupling ZHK or hydraulic hose toward the bottom	Vent screws 8 of the hydrosplit coupling ZHK
horizontal	Venting plate 5
Operating side top	Vent screws 7 at X-ES
	Vent screws 8 of the hydrosplit coupling ZHK
Туре Х-АТ, АТ	Venting points X-AT, AT
Vertical, working piston downward	Vent screws 4
Vertical, working piston upward	HP measuring connection 3
Horizontal, operating side facing upward	Vent screws 4
	HP measuring connection 3
Type HZL	Venting points HZL
Enclosed installation position	Vent screws 9

Tab. 10 Venting point according to installation position

WARNING

Contusions caused by uncontrolled extending working piston!

Serious contusions and injuries on hand and fingers.

- ➔ Make sure that the return stroke is impinged with compressed air.
- → Make sure that fast approach stroke and power stroke cannot be activated.
- → Install a restraint device if necessary.
- → Turn off compressed air supply of the pressure valve.

Environmental pollution caused by environmentally harmful liquids!

- → Absorb spilled liquids and remove without residue.
- ➔ Dispose of liquid according to the statutory regulations.



NOTE

Damage caused by trapped air!

- → Vent drive after filling with oil.
- → Use highest vent screw or high pressure measuring connection for venting.
- System is in maintenance position.
 See Set system to maintenance position, Page 103.
- 1. Remove venting plate with locking wire on the intensifier (X-ES).
- 2. Unscrew knurled cap of the oil filling nipple.
- 3. Vent filling hose of the oil pump.
- 4. Install filling hose of the oil pump on oil filling nipple.
- 5. Continue to fill until oil escapes from the vent hole free of bubbles.
- 6. **CAUTION!** Risk of slipping from leaking oil! Absorb oil immediately and without residue!
- 7. Wait 10 min. Afterwards, repeat filling procedure until oil escapes from the vent hole free of bubbles.
- 8. Deactivate power stroke. For this, turn the control throttle X fully closed.
- 9. Move the working piston several times forward and backwards without power stroke.
- 10. Continue to refill until oil escapes from the open vent hole free of bubbles.
- 11. CAUTION! Splashing oil! Open vent screw slowly!

Unscrew the corresponding vent screw (see table "Venting point according to installation position") a maximum of 2 turns until the oil comes out under the vent screw without bubbles.

Then immediately close the vent screw.

- OR -

Unscrew the corresponding high pressure measuring connection cover (see table "Venting point according to installation position") and push in with a blunt object (e.g. a pin) until the oil comes out without bubbles.

12. Move the working piston several times forward and backwards with power stroke. For this, open control throttle X until the power stroke is audibly activated.



13. CAUTION! Splashing oil! Open vent screw slowly!

Unscrew the corresponding vent screw (see table "Venting point according to installation position") a maximum of 2 turns until the oil comes out under the vent screw without bubbles.

Then immediately close the vent screw.


- OR -

Unscrew corresponding high pressure measuring connection cover (see table "Venting point according to installation position") and push in with a blunt object (e.g. a pin) until the oil comes out without bubbles.

- 14. Tighten the vent screws. For tightening torque see Tightening torques.
- 15. If necessary, unscrew the sealing cap on high pressure measuring connection.
- 16. Unscrew filling hose of the oil pump.
- 17. Screw in knurled cap of the oil filling nipple.
- 18. Install venting plate.
- 19. Fasten locking wire.
- 20. **NOTE!** Device damage due to overfilling! Lower oil level. See Lowering of oil level, Page 118.



- 10.6 Refilling oil and venting the drive of Powerpackage with optional equipment
- 10.6.1 Refilling oil and venting drive with integrated damping function ZED



- 1 Oil filling nipple
- 3 High pressure measuring connection X-ES
- 5 Venting plate
- 7 Vent screw X-ES
- 9 Vent screw ZED

- Oil level indicator
- High pressure measuring connection ZED
- 6 Oil anti-overfill safety device
- 8 Vent screw
- 10 Vent screw ZED

Material required:

- Oil, filtered < 5 μm, load rating > 30 N/mm² (in accordance with DIN 51524-2 HLP DD32)
 If different energial site are used, see sticker.
 - If different special oils are used, see sticker.
- Oil pump ZP 20



The top vent screws or the top HP measuring connection must be selected for the venting.

2

4

Venting points according to installation position

Installation position	Venting points
Type X-ES	Venting points X-ES
Vertical Hydrosplit coupling ZHK or hydraulic hose toward the top	 Venting plate 5 Vent screws 7 at X-ES HP measuring connection 3 at X-ES
	 Vent screws 8 of the hydrosplit coupling ZHK
Vertical	 Vent screws 7 at X-ES
Hydrosplit coupling ZHK or hydraulic hose toward the bottom	 Vent screws 8 of the hydrosplit coupling ZHK
horizontal	Venting plate 5
Operating side top	 Vent screws 7 at X-ES
	 Vent screws 8 of the hydrosplit coupling ZHK
Type X-ATD	Venting points X-ATD
Vertical, working piston downward	Vent screws 9, 10
	 After solenoid valve is switched on: Vent screw 11
Vertical, working piston upward	Vent screws 9, 10
	HP measuring connection 3
	 After solenoid valve is switched on: Vent screw 11
Horizontal, operating side facing upward	Vent screws 9, 10
	HP measuring connection 3
	 After solenoid valve is switched on: Vent screw 11

Tab. 11 Venting point according to installation position

A WARNING

Contusions caused by uncontrolled extending working piston!

Serious contusions and injuries on hand and fingers.

- → Make sure that the return stroke is impinged with compressed air.
- → Make sure that fast approach stroke and power stroke cannot be activated.
- ➔ Install a restraint device if necessary.
- → Turn off compressed air supply of the pressure valve.

Environmental pollution caused by environmentally harmful liquids!

- ➔ Absorb spilled liquids and remove without residue.
- \rightarrow Dispose of liquid according to the statutory regulations.



NOTE

Damage caused by trapped air!

- → Vent drive after filling with oil.
- → Use highest vent screw or high pressure measuring connection for venting.



- System is in maintenance position.
 See Set system to maintenance position, Page 103.
- 1. Remove venting plate with locking wire on the intensifier (X-ES).
- 2. Unscrew knurled cap of the oil filling nipple.
- 3. Vent filling hose of the oil pump.
- 4. Install filling hose of the oil pump on oil filling nipple.
- 5. Continue to fill until oil escapes from the vent hole free of bubbles.
- 6. **CAUTION!** Risk of slipping from leaking oil! Absorb oil immediately and without residue!
- 7. Wait 10 min. Afterwards, repeat filling procedure until oil escapes from the vent hole free of bubbles.
- 8. Deactivate power stroke. For this, turn the control throttle X fully closed.
- 9. Move the working piston several times forward and backwards without power stroke.
- 10. Continue to refill until oil escapes from the open vent hole free of bubbles.
- 11. CAUTION! Splashing oil! Open vent screw slowly!

Unscrew the corresponding vent screw (see table "Venting point according to installation position") a maximum of 2 turns until the oil comes out under the vent screw without bubbles.

Then immediately close the vent screw.

- OR -

Unscrew the corresponding high pressure measuring connection cover (see table "Venting point according to installation position") and push in with a blunt object (e.g. a pin) until the oil comes out without bubbles.

- 12. Move the working piston several times forward and backwards with power stroke. For this, open control throttle X until the power stroke is audibly activated.
- 13. CAUTION! Splashing oil! Open vent screw slowly!

Unscrew the corresponding vent screw (see table "Venting point according to installation position") a maximum of 2 turns until the oil comes out under the vent screw without bubbles.

Then immediately close the vent screw.

- OR -


Unscrew corresponding high pressure measuring connection cover (see table "Venting point according to installation position") and push in with a blunt object (e.g. a pin) until the oil comes out without bubbles.

- 14. Tighten the vent screws. For tightening torque see Tightening torques.
- 15. If necessary, unscrew the sealing cap on high pressure measuring connection.
- 16. Unscrew filling hose of the oil pump.
- 17. Screw in knurled cap of the oil filling nipple.
- 18. Install venting plate.



- 19. Fasten locking wire.
- 20. **NOTE!** Device damage due to overfilling! Lower oil level. See Lowering of oil level, Page 118.





10.6.2 Refilling oil and venting drive with cutting impact damping ZSD

Fig. 38 Refilling oil and venting drive with cutting impact damping ZSD

Material required:

 Oil, filtered < 5 μm, load rating > 30 N/mm² (in accordance with DIN 51524-2 HLP DD32)

If different special oils are used, see sticker.

• Oil pump ZP 20

The top vent screws or the top HP measuring connection must be selected for the venting.

Venting points according to installation position

Installation position	Venting points
Type X-ES	Venting points X-ES
Vertical	Venting plate 5
Hydrosplit coupling ZHK or hydraulic hose	Vent screws 7 at X-ES
toward the top	HP measuring connection 3 at X-ES
	Vent screws 8 of the hydrosplit coupling ZHK
Vertical	Vent screws 7 at X-ES
Hydrosplit coupling ZHK or hydraulic hose toward the bottom	Vent screws 8 of the hydrosplit coupling ZHK
horizontal	Venting plate 5
Operating side top	Vent screws 7 at X-ES
	Vent screws 8 of the hydrosplit coupling ZHK
Type ATSD	Venting points ATSD
Vertical, working piston downward	Vent screws 9
Vertical, working piston upward	Vent screws 9
	HP measuring connection 3
Horizontal, operating side facing upward	Vent screws 9
	HP measuring connection 3

Tab. 12 Venting point according to installation position

WARNING

Contusions caused by uncontrolled extending working piston!

Serious contusions and injuries on hand and fingers.

- → Make sure that the return stroke is impinged with compressed air.
- → Make sure that fast approach stroke and power stroke cannot be activated.
- → Install a restraint device if necessary.
- → Turn off compressed air supply of the pressure valve.

A CAUTION

Environmental pollution caused by environmentally harmful liquids!

- → Absorb spilled liquids and remove without residue.
- ➔ Dispose of liquid according to the statutory regulations.



NOTE

Damage caused by trapped air!

- → Vent drive after filling with oil.
- → Use highest vent screw or high pressure measuring connection for venting.
- System is in maintenance position.
 See Set system to maintenance position, Page 103.
- 1. Remove venting plate with locking wire on the intensifier (X-ES).
- 2. Unscrew knurled cap of the oil filling nipple.
- 3. Vent filling hose of the oil pump.
- 4. Install filling hose of the oil pump on oil filling nipple.
- 5. Continue to fill until oil escapes from the vent hole free of bubbles.
- 6. **CAUTION!** Risk of slipping from leaking oil! Absorb oil immediately and without residue!
- 7. Wait 10 min. Afterwards, repeat filling procedure until oil escapes from the vent hole free of bubbles.
- 8. Deactivate power stroke. For this, turn the control throttle X fully closed.
- 9. Move the working piston several times forward and backwards without power stroke.
- 10. Continue to refill until oil escapes from the open vent hole free of bubbles.
- 11. CAUTION! Splashing oil! Open vent screw slowly!

Unscrew the corresponding vent screw (see table "Venting point according to installation position") a maximum of 2 turns until the oil comes out under the vent screw without bubbles.

Then immediately close the vent screw.

- OR -

Unscrew the corresponding high pressure measuring connection cover (see table "Venting point according to installation position") and push in with a blunt object (e.g. a pin) until the oil comes out without bubbles.

12. Move the working piston several times forward and backwards with power stroke. For this, open control throttle X until the power stroke is audibly activated.



13. CAUTION! Splashing oil! Open vent screw slowly!

Unscrew the corresponding vent screw (see table "Venting point according to installation position") a maximum of 2 turns until the oil comes out under the vent screw without bubbles.

Then immediately close the vent screw.

- OR -

Unscrew corresponding high pressure measuring connection cover (see table "Venting point according to installation position") and push in with a blunt object (e.g. a pin) until the oil comes out without bubbles.

- 14. Tighten the vent screws. For tightening torque see Tightening torques.
- 15. If necessary, unscrew the sealing cap on high pressure measuring connection.
- 16. Unscrew filling hose of the oil pump.
- 17. Screw in knurled cap of the oil filling nipple.
- 18. Install venting plate.
- 19. Fasten locking wire.
- 20. **NOTE!** Device damage due to overfilling! Lower oil level. See Lowering of oil level, Page 118.



10.7 Lowering of oil level

Environmental pollution caused by environmentally harmful liquids!

- ➔ Absorb spilled liquids and remove without residue.
- ➔ Dispose of liquid according to the statutory regulations.

NOTE

Damage to seal due to high oil level!

After refilling and venting, lower the oil level by a defined value (lowering volume " ΔV ").

For lowering volume " ΔV " see type plate.

Material required:

- Oil pump ZP 20
- System is in maintenance position.
 See Set system to maintenance position, Page 103.
- Drive is filled and vented.
 See Refilling oil and venting drive, Page 105.
- 1. Remove venting plate with locking wire.
- 2. Unscrew knurled cap of the oil filling nipple.
- 3. Screw filling hose of the oil pump onto oil filling nipple.
- CAUTION! Risk of slipping from leaking oil! Absorb oil immediately and without residue! Remove oil quantity exactly according to lowering volume "ΔV".
- 5. Unscrew filling hose of the oil pump.
- 6. Install venting plate.
- 7. Screw on knurled cap of the oil filling nipple.
- 8. Fasten locking wire.
- 9. Push in oil level indicator needle.



10.8 Check hydraulic hose lines

All hose lines are subject to a natural aging process that limits the duration of use of the hydraulic hose lines.



Tests may only be carried out by authorized personnel.

Load stress of hydraulic hose lines	Recommended test inter- val	Recommended replace- ment intervals
Normal load	12 months	6 years (operating period including max. 2 years of storage)
 Increased loads, e.g. due to increased periods of use, e.g. multi-shift operation or short cycle times of the machine strong external and inter- nal loads (due to the hy- draulic medium) which strongly reduce the pe- 	6 months	2 years (operating period)
 riod of use of the hy- draulic hose lines manually operated ma- chines with hydraulic hose lines 		

According to national regulations, further exceptional tests of hydraulic hose lines may be necessary, e.g.

- After the installation and commissioning of the hose lines.
- After conversions on the machine, longer periods of non-use and damages due to collisions or natural events (exceptional tests).
- After repairs and maintenance on the machine which could lead to the impairment of safety.

If defects are noticed during the test of the hydraulic hose lines, they must be rectified immediately. Damaged hydraulic hose lines must not be repaired or reassembled with old, previously used components. If several hydraulic hose lines are replaced at the same time, it must be ensured that the connections or the installation sites are not mixed up.



10.9 Replacing hydraulic hoses

1

- \rightarrow Change hydraulic hoses after 6 years at the latest.
 - → Observe country-specific guidelines.
- ✓ To be carried out by service personnel only.
- → Contact authorized service personnel.

10.10 Check the holding force of the holding brake

See Check the holding force of the holding brake, Page 94.



11 Repairs

11.1 Safety during repairs

Repairs may only be carried out by trained and authorized personnel.

11.2 Changing seals

Seals may only replaced by trained and authorized service personnel.



12 Disassembly and Disposal

12.1 Safety during disassembly and disposal

The dismantling and disposal may only be carried out by trained and authorized personnel.

A DANGER

Electrical hazards in case of contact with live parts!

Electric shock, burns or death in case of contact with live parts!

- → Have all work on the electrical equipment performed by an electrician.
- ➔ Disconnect power supply.
- → Wait for residual energy to disspate safely (at least 3 minutes).

Ejecting parts and compressed air from compressed air conducting lines! Serious injuries to eyes and body cavities!

- → Always connect and disconnect lines without pressure.
- ➔ Pay attention to maximum permitted pressures.
- → Wear individual protective equipment.

Sharp edges caused by material splintering!

Injuries from worn parts!

- → Wear individual protective equipment.
- ➔ Do not move fingers along the cutting edges.
- ➔ Be particularly careful and attentive.



12.2 Decommissioning

Decommissioning means that the plant is not in operation for a longer period of time but remains at the installation site for recommissioning later.

- 1. Move plant into home position.
- 2. Install a restraint device if necessary.
- 3. Switch off plant at the main switch.
- 4. Clean the system and protect it against corrosion.
- 5. Protect plant against loss of data and deep discharge.

12.3 Shutdown

Shutdown means that the system is shut down permanently and/or is prepared for removal.

- 1. Stop system and wait for it to come to a standstill.
- 2. Remove material if necessary.
- 3. Switch off the system at the main switch and secure it against being switched on again.
- 4. First disassemble or dismantle after switching off the power (electricity, pneumatics) and after residual energy has safely dissipated (at least 3 minutes).
- 5. Remove electrical supply line (first at the terminal, then on the machine).
- 6. Remove compressed air supply line.
- 7. Remove network connection.
- 8. Clean the system and protect it against corrosion.
- 9. Protect open cable ends against penetration of dirt.
- 10. Do not remove cable identifications.



12.4 Disassembling

The system consists of recyclable materials.

NOTE

Environmental damage!

Improper recycling endangers the environment!

- → Dispose of materials separately and properly.
- → Regional disposal regulations must be observed.
- 1. Strip the system down into its constituent parts.
- 2. Dispose of greases and oils separately.
- 3. Sort the constituent parts by material and dispose of according to the local regulations.



12.5 Disposal



When disposing of packaging, consumables and spare parts, including the machine and its accessories, the relevant national environmental protection regulations must be complied with.

For the environmentally compatible utilization and disposal of its electronic components, please contact the certified disposal company for electronic waste or return it to TOX[®] PRESSOTECHNIK.

For further information about the take-back and forms see www.tox.com in the service sector.

Regarding questions about disposal please contact TOX[®] PRESSOTECHNIK SE & Co. KG (see Contact and source of supply, Page 12).



13 Appendices

13.1 DECLARATION OF INCORPORATION

DECLARATION OF INCORPORATION

in accordance with the Machinery Directive (2006/42/EC), Annex II 1 B

Original declaration of incorporation

TOX[®] PRESSOTECHNIK GMBH & CO. KG herewith declares that the concept and design of the incomplete machine specified hereinafter and the execution traded by us

Designation/function	Pneumohydraulic drive
Product name/module	TOX ^{®-} Powerpackage
Model/typ	Х-Ѕ, Х-К
	X-KT, X-ES mit X-AT, X-ES mit HZL
	X-KW
	X-ATD, X-SD, X-KD
	X-ATSD
	X-ATSL, X-SSL, X-KSL
Serial number	See type plate

complies with the relevant requirements of the Machinery Directive (2006/42/EC).

Insofar as the requirements of Annex 1 apply to the incomplete machine, the relevant health and safety requirements shall be documented in the technical documents according to Annex VII Section B.

Applied harmonized standards:

DIN EN ISO 12100:2011-03	Safety of machinery - General principles for design - Risk
	assessment and risk minimization
DIN EN ISO 4414:2011-04	Pneumatic fluid power - General rules and safety
	requirements for systems and their components

This incomplete machine may not be commissioned until it has been ascertained that the incomplete machine in which the component is to be installed complies with the requirements of the Machinery Directive (2006/42/EC).

The technical documents specific to this incomplete machine are available and can be transmitted electronically to national authorities in response to a reasoned request.

TOX°

The commercial property rights of TOX[®] PRESSOTECHNIK GMBH & CO. KG shall remain unaffected by this.

The technical documents belonging to the incomplete machine according to Annex VII Part B have been produced.

Documentation officer: Simon Köberle, Riedstraße 4, 88250 Weingarten

Place, date

Weingarten, 01.02.2018

Manufacturer

TOX[®] PRESSOTECHNIK GMBH & CO. KG

Signature

Information on the signatory: ppa Albert Rankel



Index

Symbols

(Safety lock of proximity sensors)	
Setting	91

Α

Accessories hydrosplit coupling ZHK	
Electrically switchable valve	35
Activation	
Design principles	46
Dynamic pressure method	46
Electric	45
Air consumption	39
Air pressure	
Туре X-S, Туре X-К	48
Ambient temperature	47
Avoidance of dynamic oil leakage	41

В

Basic safety requirements 13	
------------------------------	--

С

Causes of fault
Seal 121
Changeover from power stroke to return stroke
For Powerpackages with hydraulic damping
44
Changeover of power stroke to return stroke
ZED
ZED
Changing seals 121
Check
Holding force of the holding brake
Hydraulic hose lines 119
Oil level 104
Commissioning
Safety
Compressed air quality 48
Conformity 8
Connecting
Hydrosplit coupling 58
Contact
Control connection 46, 77
Control throttle 'X'
Setting
Contusion
Hazard
Correct
Construction
Design
Cutting impact damping (ZSD)
Setting
Cycle times 40



D

Damping (ZED)	
Setting 8	6
Damping effect	
Setting 8	9
Data sheet 3	8
Decommissioning 12	23
Design data 3	8
Design principles 3	8
Design principles of activation 4	6
Disassembly 122, 12	24
Safety 12	2
Dispatch	
Repair 5	5
Disposal 122, 12	25
Safety 12	2
Document	
additional	9
Validity	9
Drive	
Install 5	7
Operating 9	6
Venting 10)5
Drive with integrated damping function ZED	
Venting 10	9
Dynamic oil leakage	
Avoiding 4	1
Dynamic pressure method	
Activation 4	6

Ε

Electrical activation Electrically switchable valve	45
Accessories hydrosplit coupling ZHK	35
Hydrosplit coupling ZHK	34
Electromagnetic	
Hazard	17
Environmental conditions	47
Equipment	
Optional	37
Exclusion of liability	. 8
External power stroke connection (ZKHZ)	
Installing	70
External power stroke release (ZKHF)	
Installing	71

F

Fast approach stroke	23
Function description	22

G

Gender note	9
General information	
Maintenance	101
Guidelines	8



н

Hazard	
Contusion	16
Electrical	15
electromagnetic	17
Hazardous substances	17
hydraulic	16
Laser	17
Lithium ion battery	18
Noise	18
Pneumatic	15
Thermal	15
Hazard potential	15
Hazardous substances	17
Holding brake	
ZSL	45
Holding force of the holding brake	
Check	94
Hydraulic	
Hazard	16
Hydraulic damping	
Changeover from power stroke to return	
stroke	44
Hydraulic hose lines	
Check 1	
Installing	
Product attributes	
Product overview	36
Hydraulic oil	
Specification	51
Hydraulic screwings	
Tightening torques	50
Hydrosplit coupling	
Connecting	
Separating	58
Hydrosplit coupling ZHK	
5	
5	
Product overview	33

I

Identification	
Product	. 21
Images	
Highlighting	. 11
Important information	8
Information	
Important	8
Installation	. 56
Accessories	. 61
Drive	. 57
External power stroke switch (ZKHZ)	. 70
Power stroke deactivation (ZKHD)	. 71
Power stroke release (ZKHF)	. 71
Pressure control in the power stroke line (ZDK)	. 67
Proportional pressure control valve	. 69
Safety	. 56
Speed reduction for power stroke	. 75
Stroke frequency optimization (ZHO) for	
drive with integrated power stroke valv	e
Tishtaning targuas	
Tightening torques	
Tool coupling (ZWK) ZDK	
ZDR ZHO	
ZHU ZKHD	
ZKHD	
ZKHZ	
ZWK	
Installing	. 70
Hydraulic hose lines	60
Position sensors of stroke monitoring for	
ward and return stroke (ZHU)	
Pressure switch	
Stroke frequency optimization (ZHO)	
ZDO	
ZHO	. 73
Installing accessories	. 61
Installing pressure control in the power strok line (ZDK)	e
Installing tool coupling (ZWK)	
Installing ZDK	
Installing ZWK	
Instructions	
Tool installation	. 76
Integrated holding brake	
Product overview	. 30



Integrated holding brake ZSL	
Product attributes	30
Intended use	19

L

Laser	
Hazard	17
Legal note	8
Lifting device	54
Lowering	
Oil level	118

Μ

General information
•
Safety 101
Maintenance position 103
Manually switchable
Hydrosplit coupling ZHK 33
Measures
Organizational 13
Measuring connection 46, 77
Misuse 20

Ν

Noise Hazard	18
Note	
Gender	9
General	11
Legal	8
Warning signs	10

0

Oil	
Refilling	. 105, 109, 114
Oil leakage	
Avoiding	41
Oil level	
Checking	104
Lowering	118
Oil pressure	
Type X-S, Type X-K	48
Operation	
Drive	
Requirements	
Safe	19
Safety	
Optional	
Equipment	37
Organizational measures	13

TOX®

Ρ

Performance optimization Piston rod	41
Tightening torques	49
Pneumatic connection	
Pneumatic screw fittings on the Powerpackag	ae
Tightening torques	-
Position sensors of stroke monitoring for for-	
ward and return stroke (ZHU)	
Installing	63
Power limit	
Power stroke	44
Power stroke	24
Installing speed reduction	
Power limit	
Speed reduction	
Stroke limitation	
Power stroke connection (ZKHZ)	
Installing	70
Power stroke deactivation (ZKHD)	10
Installing	71
Power stroke release (ZKHF)	11
Installing	71
Preparation	11
•	70
Power stroke supply, external	
Preparing external power stroke supply	
Preparing external power stroke supply	72
Press force table	51
Pressure switch	~
Installing	61
Product attributes	~ ~
Hydraulic hose lines	
Integrated holding brake ZSL	
Type AT, AT 51, ATSD, ATW	
Type HZL, HZL 51, HZL - pulling, HZLW	
Type RZHL, RZHLW	
Type X-AT, X-ATD	
X-KT system	
Product Identification	21
Product overview	
Hydraulic hose lines	36
Hydrosplit coupling ZHK	33
Integrated holding brake	
Type AT, AT 51, ATSD, ATW	29
Type HZL, HZL 51, HZL - pulling, HZLW	31
Type RZHL, RZHLW	32
Type X-AT, X-ATD	27

X-KT system	26
Proportional pressure control valve	
Installing	69
Proximity sensors of the holding brake	
Setting	91

Q

Qualifications14	4
------------------	---

R

Refilling Oil
Repair
Dispatch 55
Repairs 121
Safety 121
Replace
hydraulic hoses 120
Replacing hydraulic hoses 120
Requirement
Maintenance 103
Return stroke 25



S

Safe
Construction
Design
Safety
Commissioning
Disassembly 122
Disposal
Installation
Maintenance 101
Operation
Repairs 121
Transport
Troubleshooting
safety requirements
Basic 13
Operating company 13
Selection
Personnel 14
Selection of personnel 14
Separating
Hydrosplit coupling 58
Set
Speed ratio between power stroke and
power stroke venting 42, 79
Setting
Control throttle 'X' 78
Cutting impact damping (ZSD) 89
Damping (ZED) 86
Proximity sensors of the holding brake 91
Safety lock of proximity sensors 91
Speed ratio between return stroke and fast
approach stroke 42, 79
Total length of stroke 85
Settingt
Damping effect
Shutdown 123
Source of supply 12
Specification for hydraulic oil 51
Speed ratio between power stroke and power
stroke venting
Set
Speed ratio between return stroke and fast approach stroke
Setting 42, 79
Speed reduction
Power stroke
Speed reduction for power stroke

Installing7	'5
Storage5	53
Temporary storage5	64
Stroke frequency optimization (ZHO)	
Installing7	'3
Stroke frequency optimization (ZHO) for drive with integrated power stroke valve	
Installing7	'3
Stroke limitation	
Power stroke 4	-3



Т

Target group		
Technical data		
Technical design data		
Texts		
Highlighting	11	
Tightening torque		
Tightening torque of hydrosplit coupling	50	
Tightening torque of hydrosplit coupling		
Tightening torque	50	
Tightening torques		
Hydraulic screwings	50	
Installation		
Piston rod		
Pneumatic screw fittings on the Powerpac		
age		
total stroke adjustment	49	
Tool installation		
Instructions	76	
Total length of stroke		
Setting	85	
Total stroke adjustment		
tightening torques	49	
Transport	53	
Safety	53	
Troubleshooting	97	
Safety	97	
Type AT, AT 51, ATSD, ATW		
Product attributes	29	
Product overview	29	
Type HZL, HZL 51, HZL - pulling, HZLW		
Product attributes	31	
Product overview	31	
Type plate	21	
Type RZHL, RZHLW		
Product attributes	33	
Product overview	32	
Type X-AT, X-ATD		
Product attributes	28	
Product overview	27	
Type X-S, Type X-K		
Air pressure	48	
·		

V

Validity	
Document	. 9
Venting	
Drive 1	05
Drive with integrated damping function ZE	
1	09

W

Warning	signs	10
---------	-------	----

Χ

X-KT system	
Product attributes	26
Product overview	26

Ζ

ZDO
Installing61
ZHO
Installing73
ZKHD
Installing71
ZKHF
Installing71
ZKHZ
Installing70
ZSL
Holding brake 45

U

Use	
Intended	19



